

USERGUIDE  
UGE010/0597

# Fan Cutter Pelletizer (Model 2512)



**WARNING - Reliance on this Manual Could Result in Severe Bodily Injury or Death!**

This manual is out-of-date and is provided only for its technical information, data and capacities. Portions of this manual detailing procedures or precautions in the operation, inspection, maintenance and repair of the product forming the subject matter of this manual may be inadequate, inaccurate, and/or incomplete and cannot be used, followed, or relied upon. Contact Conair at [info@conairgroup.com](mailto:info@conairgroup.com) or 1-800-654-6661 for more current information, warnings, and materials about more recent product manuals containing warnings, information, precautions, and procedures that may be more adequate than those contained in this out-of-date manual.

**1. FORWARD**

**2. INSTALLATION AND OPERATION**

Safety Instructions ..... 2-1  
Precautions ..... 2-1  
Power and Utility Requirements ..... 2-2  
Operation Procedures ..... 2-3

**3. MAINTENANCE & ADJUSTMENTS**

Rotor Knife Blade and Knife Replacement and Adjustment ..... 3-1  
Feedroll Replacement and Adjustment ..... 3-2  
Drive Part Replacement and Adjustment ..... 3-3  
Lubrication, Bearings, Motors, Etc. .... 3-4  
    Feedrolls ..... 3-4  
    Rotors ..... 3-4

**4. RECOMMENDED SPARE PARTS**

Model 2512 Fan Cutter Spare Parts List ..... 4-1

**5. DRAWINGS AND PARTS LIST**

2512 Fan Cutter - Floor Plan (Dwg. 2512-55)  
Fan Cutter Assy. (Dwg. 2512-55-1)  
Rotor Assembly (Dwg. 2512-55-2)  
Feedroll Assembly (Dwg. 2512-55-3)  
2512 Fan Cutter - Wiring Diagram (Dwg. 2512-480)

# **MODEL 2512 FAN CUTTER**

---

## **FORWARD**

Proper installation, operation, and maintenance procedures are critical, however, for achieving optimum equipment performance, as well as for insuring operator safety. This manual provides an overview of the system design features, suggested installation steps, recommended start-up and operation procedures, possible troubleshooting needs, maintenance schedules and procedures, service and spare parts recommendations, and key reference materials on the system and its commercially available components.

Each user may have different procedures, techniques, tools, and parts for operating and maintaining its pelletizing lines. Also, the skills of the individuals doing the work may vary. As such, this manual cannot possibly anticipate all such variations and provide advice or cautions as to each. Accordingly, anyone who departs from the instructions in this manual must first establish that neither personal safety nor equipment integrity will be compromised by the choice of methods, tools, or parts.

As you read through the procedures in this manual, you will come across NOTES, CAUTIONS, and WARNINGS. Each is listed for a specific purpose. NOTES give you added information to help you complete a particular procedure. CAUTIONS are given to prevent you from making an error that could damage the equipment. WARNINGS remind you to be especially careful where personal injury may result.

The recommendations and suggestions in this manual are made to help you with your Conair Jetro Model 2512 Fan Cutter Strand Pelletizing System. It is not meant to supersede individual company policies or override OSHA safety requirements.

**SAFETY INSTRUCTIONS**

This pelletizer should not be installed, operated or worked upon without compliance with the warning signs affixed and a thorough understanding of these instructions.

**PRECAUTIONS**

1. Always disconnect power completely before attempting any service to the unit.
2. Never operate the unit with the cutting chamber cover removed, or in poor condition.
3. Never operate the unit with the guards or discharge chute removed.
4. Do not attempt to override safety switches or overloads.
5. Always allow the unit to clean out before shutting it down; do not feed material to the unit when it is not operating.
6. Prevent all metal and foreign material from entering the cutting chamber; this pelletizer is intended to cut plastic material only.
7. Do not operate this machine without proper training.
8. **WARNING: STRANDS ARE HOT!!!**

**POWER AND UTILITY REQUIREMENTS**

The standard model FC-2512 Fan Cutter pelletizer has electrical power connection to a flush mounted NEMA 12 enclosure in the base of the machine.

WARNING: MAKE SURE POWER IS DISCONNECTED AT THE MAIN SOURCE BEFORE CONNECTING.

a. **Electrical Power Requirements:**

Standard Drives are 3 HP and 1 HP AC motors electrical power service required is: 460 Volt, 3 Phase, 60 Hertz and power is 11 KVA draw.

Ref: Drawing No. 2512-480, FC2512 Wiring Diagram.

Optional Drive is 5 HP and 1 HP motors, 11 KVA power draw. (460 V, 3 PH, 60 Hertz)

b. **Utility Requirements:**

Air supply of 40 to 80 psi gauge - connection to air regulator is located on the upper base at this flow regulation valve marked feedroll "OPEN" or "CLOSED" position.

WARNING: MAKE SURE ALL MACHINE GUARDS ARE CLOSED AND SECURED IN PLACE BEFORE CONNECTION AND ACTUATION OF THE FEEDROLL AIR CONTROL VALVE.

**OPERATION PROCEDURES**

1. Position the machine in line with the exiting strands at the die on the extruder.

WARNING: MAKE SURE THE POWER IS DISCONNECTED AT THE MAIN SOURCE AND THE ELECTRICAL CONTROL ENCLOSURE DISCONNECT SWITCH IS LOCKED OUT BEFORE OPENING THE MACHINE FOR SERVICE OR MAINTENANCE. REFER ALSO TO SAFETY INSTRUCTIONS.

2. Insure that all safety interlocks are closed and all guards and covers on the machine are in place and securely fastened so the operator may not be injured by rotating components of the machine.
3. Connect all electrical power to the machine main electrical enclosure, following the schematic instructions for the appropriate model and serial number of the machine. Also see instructions of section 2.0 Power and Utility Requirements.
4. Connect the pneumatic air line to the pressure regulator fitting on the machine and set pressure to a maximum of 30 psi. Position the feedroll air pressure valve lever to the "OPEN" position. Also see instructions of section 2.0 Power and Utility Requirements.
5. Press the Operator Control station "START" button and set the rotor speed potentiometer to near maximum speed setting. Next, set the feedroll speed potentiometer to 50% of maximum speed.
6. Start the extruder and purge strands for uniform flow. Gather strands of plastics and submerge through the water bath and pass the air knife and into the feed opening of the pelletizer. Make the following adjustments:
  - a. Close the feedroll, by moving the feedroll air pressure valve lever to the "CLOSE" position.
  - b. Adjust the feedroll speed potentiometer to pull strands into tension according to extruder output and the desired strand diameter.
  - c. Adjust the extruder output and feedroll speed potentiometer for strand tension to avoid tangles or slack of the strands. Separate and space strands uniformly in the grooves provided across the pelletizer's infeed strand guide.
7. Make rotor speed adjustments to produce the "cut length" desirable. Usually strand sizes range from .020" long at maximum speed to a nominal .125" long cuts at 25% of full rotor speed setting. Inspect output pellets and make necessary speed adjustments.
8. Cut length to strand diameter adjustments (pellet L/D):
  - a. For various pellet cut length changes and strand diameter adjustments, first increase or decrease the feedroll speed potentiometer to refine the strand diameter.
  - b. Secondly, make the rotor speed adjustment up or down to increase or decrease the cut lengths.
9. Shut Down Sequence:
  - a. Maintain the set pelletizer feedroll speed setting until the extruder has discharged all material and slowly decrease the extruder screw speed to "0" rpm.
  - b. Run the pelletizer until all strands have been cut and material no longer discharges from the machine. Open the feedrolls to release remaining small size strands.
  - c. Shut down the pelletizer by depressing the "Stop" button on the operator control station and turn the main power disconnect "Off".
  - d. Disconnect electrical and air supply before maintenance or cleanout.

**ROTOR KNIFE BLADE & BED KNIFE REPLACEMENT AND  
ADJUSTMENT**

WARNING: MAKE SURE THE POWER IS DISCONNECTED AT THE MAIN SOURCE AND THE ELECTRICAL CONTROL ENCLOSURE DISCONNECT SWITCH IS LOCKED OUT BEFORE OPENING THE MACHINE FOR SERVICE OR MAINTENANCE. REFER ALSO TO SAFETY INSTRUCTIONS.

Blades should be replaced when they show signs of wear, become dull or show nicks and chips.

All of the blades should be replaced as a set.

To replace a set of knife blades, first **disconnect power**. Loosen feedroll motor mounting bolts and adjust motor up to remove belts. Remove post mounting plate bolts (see Dwg. #2512-26) and then remove feedroll assembly. This should allow you access to the rotor and knife blades. When removing blades, be sure to block rotor from turning before loosening knife blade bolts. Reassemble replacement blades making sure rotor is still blocked to prevent free turning. Torque knife blade bolts to 14 Ft./Lbs. (Blue thread lock optional). Once knife blades are assembled, the gap between the blades and the bed knife needs to be adjusted. If the bed knife strand surface shows wear or the carbide insert becomes chipped it should be replaced. Loosen mounting bolts to bed knife and slide bed knife to knife blades. Adjust the gap between knife blade and bed knife with .001" feeler gauge. Be sure to check each blade. Tighten bed knife bolts and then you can reassembly the feedroll assembly.

Before assembling the feedroll assembly, adjust the bed knife gap between the rotor blade and the bed knife. Loosen bolts on the bed knife. With a feeler gage of .001", set gap between blade and bed knife by sliding bed knife towards blades with feeler gage in between. Spin rotor to check all blades. Once the bed knife is set, assemble feedroll assembly. Then tighten bed knife bolts.

**FEEDROLL REPLACEMENT AND ADJUSTMENT**

WARNING: MAKE SURE THE POWER IS DISCONNECTED AT THE MAIN SOURCE AND THE ELECTRICAL CONTROL ENCLOSURE DISCONNECT SWITCH IS LOCKED OUT BEFORE OPENING THE MACHINE FOR SERVICE OR MAINTENANCE. REFER ALSO TO SAFETY INSTRUCTIONS.

The upper feedroll should be replaced when the outside diameter of the hypalon coating shows cuts, tears, and/or worn grooves.

When adjusting the upper feedroll, cylinders, cylinder mounting plate and cylinder rod ends, right and left guide brackets, slide into the left and right hand post. The cylinder mounting plate bolts to the posts. To adjust strand guides, remove upper feedroll assembly and adjust set screws in bed knife to height needed. To remove strand guide, remove upper feedroll assembly, remove bolts to air cylinder with slot in mounting plate. Loosen set screw in cylinder rod end and slide cylinder out of mounting plate. Strand guide will drop out. Reassemble cylinder to mounting plate and left and right hand posts.

**DRIVE PART ADJUSTMENT AND REPLACEMENT**

WARNING: MAKE SURE THE POWER IS DISCONNECTED AT THE MAIN SOURCE AND THE ELECTRICAL CONTROL ENCLOSURE DISCONNECT SWITCH IS LOCKED OUT BEFORE OPENING THE MACHINE FOR SERVICE OR MAINTENANCE. REFER ALSO TO SAFETY INSTRUCTIONS.

**1. ROTOR:**

Drive part adjustment and replacement for cutter rotor (3 HP and optional 5 HP motor):

- a. Proper adjustment of belts requires loosening the motor mounting bolts and adjusting the sliding motor base bolts to tighten or loosen the drive belts.
- b. Replacement of rotor drive belts requires loosening motor mounting bolts and moving the adjustable motor base to loosen the belts to the point that they may be removed over the motor sheave. Remove and replace with new rotor drive belts (Conair Part No. 3413-30104) and adjust to tension and tighten.

**2. FEEDROLL:**

Drive part adjustment and replacement (1 HP motor):

- a. Proper adjustment of belts requires loosening the motor mounting bolts and adjusting the sliding motor base bolts to tighten or loosen the feedroll belts.
- b. Replacement of feedroll drive belts requires loosening motor mounting bolts and moving the adjustable motor base bolts to loosen the belts to the point that they may be removed over the motor sheave. Remove and replace with new feedroll drive belts (Conair Part No. 3513-30112) and adjust to tension and tighten.



**LUBRICATION, BEARINGS, MOTORS, ETC.****Feedrolls**

All feedroll bearings are sealed bearings and do not need to be greased. If bearings fail, they should be replaced. Upper feedroll bearing, Conair Part No. 3558-50088 (2), Lower feedroll bearing, Conair Part No. #3558-30072 (1) and #3558-30088 (4).

**Rotors**


Grease fittings for the rotor bearings are remotely located so that the rotor bearings can be greased with a standard pressure gun. They should be greased periodically.

Use only LINIREX N3 grease from EXXON CO.



**RECOMMENDED SPARE PARTS**

<u>ITEM DESCRIPTION</u>	<u>PART NUMBER</u>	<u>QUANTITY</u>
Upper Feedroll	2512-20	1
Lower Feedroll-Ceramic	2512-25-3	1
Bed Knife Block	2512-27	1
Rotor Blades-Stellite	2512-5-3	12 (Set)
Rotor Drive Belt	3513-30104	2
Feedroll Drive Belt	3513-30112	1
Rotor Bearing	3559-30016	2
Feedroll Bearing	3558-30088	6
Feedroll Bearing	3558-30072	1






45	1	2512-12-1	LEFT SIDE NAIL
46	1	2512-12-2	RIGHT SIDE NAIL
47	1	2512-12-3	ROTOR BLADE BRACKET
48	1	2512-12-4	ROTOR BLADE COVER
49	1	2512-12-5	FEED WHEEL BOTTOM TRAY
50	1	2512-12-6	FEED WHEEL BLADE
51	1	2512-12-7	FEED WHEEL BLADE
52	1	2512-12-8	FEED WHEEL BLADE
53	1	2512-12-9	FEED WHEEL BLADE
54	1	2512-12-10	FEED WHEEL BLADE
55	1	2512-12-11	FEED WHEEL BLADE
56	1	2512-12-12	FEED WHEEL BLADE
57	1	2512-12-13	FEED WHEEL BLADE
58	1	2512-12-14	FEED WHEEL BLADE
59	1	2512-12-15	FEED WHEEL BLADE
60	1	2512-12-16	FEED WHEEL BLADE
61	1	2512-12-17	FEED WHEEL BLADE
62	1	2512-12-18	FEED WHEEL BLADE
63	1	2512-12-19	FEED WHEEL BLADE
64	1	2512-12-20	FEED WHEEL BLADE
65	1	2512-12-21	FEED WHEEL BLADE
66	1	2512-12-22	FEED WHEEL BLADE
67	1	2512-12-23	FEED WHEEL BLADE
68	1	2512-12-24	FEED WHEEL BLADE
69	1	2512-12-25	FEED WHEEL BLADE
70	1	2512-12-26	FEED WHEEL BLADE
71	1	2512-12-27	FEED WHEEL BLADE
72	1	2512-12-28	FEED WHEEL BLADE
73	1	2512-12-29	FEED WHEEL BLADE
74	1	2512-12-30	FEED WHEEL BLADE
75	1	2512-12-31	FEED WHEEL BLADE
76	1	2512-12-32	FEED WHEEL BLADE
77	1	2512-12-33	FEED WHEEL BLADE
78	1	2512-12-34	FEED WHEEL BLADE
79	1	2512-12-35	FEED WHEEL BLADE
80	1	2512-12-36	FEED WHEEL BLADE
81	1	2512-12-37	FEED WHEEL BLADE
82	1	2512-12-38	FEED WHEEL BLADE
83	1	2512-12-39	FEED WHEEL BLADE
84	1	2512-12-40	FEED WHEEL BLADE
85	1	2512-12-41	FEED WHEEL BLADE
86	1	2512-12-42	FEED WHEEL BLADE
87	1	2512-12-43	FEED WHEEL BLADE
88	1	2512-12-44	FEED WHEEL BLADE
89	1	2512-12-45	FEED WHEEL BLADE
90	1	2512-12-46	FEED WHEEL BLADE
91	1	2512-12-47	FEED WHEEL BLADE
92	1	2512-12-48	FEED WHEEL BLADE
93	1	2512-12-49	FEED WHEEL BLADE
94	1	2512-12-50	FEED WHEEL BLADE
95	1	2512-12-51	FEED WHEEL BLADE
96	1	2512-12-52	FEED WHEEL BLADE
97	1	2512-12-53	FEED WHEEL BLADE
98	1	2512-12-54	FEED WHEEL BLADE
99	1	2512-12-55	FEED WHEEL BLADE
100	1	2512-12-56	FEED WHEEL BLADE
101	1	2512-12-57	FEED WHEEL BLADE
102	1	2512-12-58	FEED WHEEL BLADE
103	1	2512-12-59	FEED WHEEL BLADE
104	1	2512-12-60	FEED WHEEL BLADE
105	1	2512-12-61	FEED WHEEL BLADE
106	1	2512-12-62	FEED WHEEL BLADE
107	1	2512-12-63	FEED WHEEL BLADE
108	1	2512-12-64	FEED WHEEL BLADE
109	1	2512-12-65	FEED WHEEL BLADE
110	1	2512-12-66	FEED WHEEL BLADE
111	1	2512-12-67	FEED WHEEL BLADE
112	1	2512-12-68	FEED WHEEL BLADE
113	1	2512-12-69	FEED WHEEL BLADE
114	1	2512-12-70	FEED WHEEL BLADE
115	1	2512-12-71	FEED WHEEL BLADE
116	1	2512-12-72	FEED WHEEL BLADE
117	1	2512-12-73	FEED WHEEL BLADE
118	1	2512-12-74	FEED WHEEL BLADE
119	1	2512-12-75	FEED WHEEL BLADE
120	1	2512-12-76	FEED WHEEL BLADE
121	1	2512-12-77	FEED WHEEL BLADE
122	1	2512-12-78	FEED WHEEL BLADE
123	1	2512-12-79	FEED WHEEL BLADE
124	1	2512-12-80	FEED WHEEL BLADE
125	1	2512-12-81	FEED WHEEL BLADE
126	1	2512-12-82	FEED WHEEL BLADE
127	1	2512-12-83	FEED WHEEL BLADE
128	1	2512-12-84	FEED WHEEL BLADE
129	1	2512-12-85	FEED WHEEL BLADE
130	1	2512-12-86	FEED WHEEL BLADE
131	1	2512-12-87	FEED WHEEL BLADE
132	1	2512-12-88	FEED WHEEL BLADE
133	1	2512-12-89	FEED WHEEL BLADE
134	1	2512-12-90	FEED WHEEL BLADE
135	1	2512-12-91	FEED WHEEL BLADE
136	1	2512-12-92	FEED WHEEL BLADE
137	1	2512-12-93	FEED WHEEL BLADE
138	1	2512-12-94	FEED WHEEL BLADE
139	1	2512-12-95	FEED WHEEL BLADE
140	1	2512-12-96	FEED WHEEL BLADE
141	1	2512-12-97	FEED WHEEL BLADE
142	1	2512-12-98	FEED WHEEL BLADE
143	1	2512-12-99	FEED WHEEL BLADE
144	1	2512-12-100	FEED WHEEL BLADE

PART USER: \_\_\_\_\_  
 DRAWING NO. \_\_\_\_\_ SCALE: 1:1 DATE: 8-9-74  
 TOLERANCES (UNLESS OTHERWISE SPECIFIED):  
 FRACTIONS DECIMALS MILLIMETERS  
 DECIMALS INCHES MILLIMETERS  
 DIMENSIONAL NO. 2512-551  
 CHECKED BY: \_\_\_\_\_  
 DESIGNED BY: \_\_\_\_\_  
 CONAIR JETRO FAN-CUTTER ASSY  
 FILE NO. 2512-551










QTY	SYMBOL	DESCRIPTION
25	1	85337 MOTOR TATUNG AC 5 HP
24	1	85281 DRIVE ABB ACS201-09-3-00P10
23	1	1810-30064 MAIN STARTER K.L.M.R.PK.241-10
25	1	85336 MOTOR TATUNG AC 3 HP
24	1	85280 DRIVE ABB ACS201-09-3-00P10
23	1	1810-30040 MAIN STARTER K.L.M.R.PK.241-8
22	1	1801-30032 RELAY K.L.M.J.ROLER40
21	1	84037 SW. TELE. #4501503-00
20	1	85316 SW. K.L.M.P. AT0-11-1-28
19	1	2523-30484 LIND. REL. M.L. #AS-111 SIMAT
18	1	1593-30456 LIND. REL. M.L. #AS-110 STOP
17	1	2523-30456 LIND. REL. M.L. #AS-110 STOP
16	1	1593-30456 LIND. REL. M.L. #AS-110 STOP
15	2	1818-00158 PICKUP TELE. #S10M0A370
14	2	1850-30006 POWER SUPPLY-RED LON
13	2	85448 RATE IND. FLUON #85448
12	1	1508-30328 CHRG. REL. MUR. FAZCI
11	1	85353 SL. 0 TRANSFORMER 100VA
10	2	1288-30000 POT. W/DIAL #1810-8001
9	1	85384 MOTOR TATUNG AC 1 HP
8	1	85393 DRIVE ABB ACS201-09-3-00P10
7	1	1810-30024 MAIN STARTER K.L.M.R.PK.241-2
6	1	1508-30320 CHRG. REL. MUR. FAZCI-3-H
5	4	1811-30120 SHAFT EXT. K.L.M.L. #2AV-10
4	4	1811-30180 INTERLOCK EXT. K.L.M.L. #V-10
3	1	1811-30112 DISC. SW. K.L.M.L. #P-25/V/SVB
2	1	85384 MOTOR TATUNG AC 1 HP
1	1	2512-54 PANEL & ENCLOSURE



FIRST USED: REF. B.M. 2512-0057 THRU 0059  
 ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED:  
 TOLERANCES (UNLESS OTHERWISE SPECIFIED):  
 XX ± 0.10 XX ± 0.05 XX ± 0.02  
 CHECKED BY: SHI... OF 1... SH15

NAME: 2512 FAN CUTTER 480V  
 DRAWING NO.: 2512-480  
 SCALE: 1:2  
 DATE: 10/02/83  
 CONAR JETRO  
 MATERIALS LIST: QTY, MATL/PART, DESCRIPTION