

USERGUIDE

# PC-1 Programmable Controller



## **WARNING - Reliance on this Manual Could Result in Severe Bodily Injury or Death!**

This manual is out-of-date and is provided only for its technical information, data and capacities. Portions of this manual detailing procedures or precautions in the operation, inspection, maintenance and repair of the product forming the subject matter of this manual may be inadequate, inaccurate, and/or incomplete and cannot be used, followed, or relied upon. Contact Conair at [info@conairgroup.com](mailto:info@conairgroup.com) or 1-800-654-6661 for more current information, warnings, and materials about more recent product manuals containing warnings, information, precautions, and procedures that may be more adequate than those contained in this out-of-date manual.

INSTRUCTIONS for use of HARMO programmable controller, type PC-1

1. Operating Switch Board

a) Key Selector Switch (Type No. ASW3K3S-243)

- 3 position selector permits to select -
1. MODE SETTING
  2. ROBOT - ON
  3. LOCK for automatic operation

(Main supply switch is located inside of control box cabinet on back-side wall.)

- |                 |   |
|-----------------|---|
| 1. MODE SETTING | MODE SELECTION switches can be operated.  |
| 2. ROBOT - ON   | When AUTOMATIC OPERATION STOP switch is ON, MANUAL OPERATION switches can be used.<br>AUTOMATIC OPERATION START switch is available to press for starting automatic operation of ROBOT interlocking to the injection molding machine when MOLD OPEN indication lamp of STATUS OF INJECTION MACHINE stays OFF. |
| 3. LOCK         | The switching KEY can be removed off at this position for security so that any push button switch on the operating switch board can not be operated.  |

b) Emergency Stop (Type No. AVW302-R)

2NC contacts Push-lock Turn Reset push-button switch interrupts immediately all the movements of not only the robot but also the injection molding machine depending on its control system.

This emergency stop operation can be released by turning the knob to clockwise (arrow mark), but the main cylinder arm assembly should be returned to its home position or starting position by means of manual operation so that the automatic operation cycle start is allowed.

c) Releasing interlocking circuit with injection machine

When the injection molding machine is to be operated without robot, turn the Key Selector Switch onto ROBOT-ON position and press STOP button switch of AUTOMATIC OPERATION. Then turn the Key Selector Switch on to LOCK position. Now, injection molding machine can be operated free from interlocking circuit of ROBOT.

#### d) Mode Selection

Turn the Key Selector Switch on to MODE SETTING position so that all the switches of MODE SELECTION group are available to operate to select any alternative standard program already stored in memory.

Press any of the push button switch, except MODE SET, first. A number for pre-set on delivery will be displayed on MODE INDICATOR. For an example, press the illuminating push button switch for CYLINDER so that a number, i.e. 1, will be displayed on MODE INDICATOR to show the pre-selected program is for the use of MAIN cylinder arm only.

If the illuminating push button switch flashes when it is pressed, it means there is no pre-set program stored in RAM memory. - Normally, standard operation program is stored and the standard operation mode is pre-selected on delivery.

REMARK : If any of push button switch, except those for option, flashes, it means all the memories in RAM have lost due to the back-up battery problem. Replace the back-up battery and set the operation mode again.

For MODE SELECTION, press any of illuminating push button switch and then press the push button switch for MODE SET so that a number will be displayed on MODE INDICATOR. Keep pressing MODE SET push button switch until any of number required for mode selection will come on the display.

The standard operation program with the different operation modes is ready stored in P-ROM IC and the selected operation mode is to be stored in a RAM memory.

#### e) Standard operation program stored in P-ROM IC.

##### (1) CYLINDER

Three (3) different modes can be selected for use.

1. MAIN cylinder arm only.
2. Both of MAIN & SUB cylinder arms together.
3. SUB cylinder arm only.

##### (2) PICK UP VERIFICATION

For security purpose, molding(s) being taken out and picked up should be detected by any means of PICK UP VERIFICATION switches to be selected from the followings.

1. LS-4, standard pick-up verification switch.
2. AUXiliary switch(es) at option.
3. Both of VACUUM differential switch and AUXiliary switch together.
4. VACUUM differential switch(option) only.

### (3) MAIN CYL. SPRUE RELEASING POSITION

The sprue or any molding part being taken hold by gripper on chuck of main cylinder arm can be released to drop

1. ON THE WAY OUTWARD of traverse at the point being set by LS-9.
2. at TRAVERSE END stop position.
3. ON THE WAY INWARD of traverse at the point being set by LS-9.
4. OFF (Not in use)

### (4) SUB CYL. SPRUE RELEASING POSITION

The sprue being taken hold by gripping fingers of sub cylinder arm can be released to drop

1. ON THE WAY OUTWARD of traverse at the point being set by LS-9.
2. at TRAVERSE END stop position.
3. ON THE WAY INWARD of traverse at the position being set by LS-9.

### (5) HOME POSITION

The home position where the robot starts the automatic operation cycle can be selected alternatively,

1. ABOVE MOLD (on the fixed platen), or
2. at the outward TRAVERSE END stop position.
3. at any point on MIDWAY of TRAVERSE, to order.

### (6) WRIST HORIZONTAL

Gripping chuck unit can be tilted to horizontal position

1. ABOVE MOLD, before traverse outward.
2. at the TRAVERSE END position before the descent.

### (7) WRIST RETURN VERTICAL

Gripping chuck unit can be tilted to return vertical position

1. ABOVE MOLD after traverse inward.
2. at the TRAVERSE END before traverse inward.

(8) INJECTION MACHINE EJECTION TIMING

Knock-out ejector of injection molding machine can be actuated

1. ON ROBOT GRIPs the moldings.
2. ON KICK FORWARD (as gripper is approaching)

(9) SECOND DESCENT 1. ON (required).

2. OFF (Not required).

(10) NIPPER CUT TIMING

Gate cutting nippers being equipped on the chuck can be operated.

0. OFF (Not required)
1. At POSITIONING HORIZONTAL position
2. At SECOND DESCENT END position

(11) OPTIONS

Special programs can be stored upon request.

f) Manual Operaton

Key Selector Switch is to be set on to ROBOT ON position and, when MOLD OPEN lamp at STATUS OF INJECTION MACHINE is illuminated, any of manual operation switch can be used.

g) AUTOMATIC OPERATION

Now, when you finished operation MODE SELECTION, mechanical stroke setting and fine adjustment of parts gripping point, you can start mold closing of injection molding machine. As the mold being closed, press the START push button switch for AUTOMATIC OPERATION so that ROBOT will start automatically when the mold open is completed.

When the main arm cylinder assembly is not at the proper home position to start, ROBOT will not start its operation cycle and any of the following Alarm Number will be displayed on TROUBLE INDICATOR.

| Alarm Number | Description  |
|--------------|--|
| 001          | The main arm cylinder assembly is not above the mold area, or not at the traverse inward end position, ( LS-2 stays OFF) |
| 002          | The gripping unit mounting plate is not at the vertical position. (LS-8 stays OFF)                                       |
| 003          | The main arm cylinder assembly is not at the upward end position. (LS-3 stays OFF)                                       |
| 004          | The main arm cylinder assembly is not at kick-backward end position. (LS-6 stays OFF)                                    |
| 005          | Any of verification switch stays ON.   |
| 006          | Traverse mid point limit switch (LS-9) stays ON.   |
| 007          | Traverse outward end limit switch stays ON.  |
| 010          | Main arm cylinder downward end limit switch (LS-11) stays ON.  |
| 011          | The gripping unit mounting plate is at the horizontal position. (LS-10 stays ON)   |
| 012          | SAFETY GATE OPEN   |
| 013          | PRESS NOT IN AUTO  |

If it happens as one of the above, operate the robot manually to set at the proper position and press RESET push button switch of TROUBLE INDICATOR.

## h) TROUBLE INDICATING ALARM NUMBERS

- 100 ... Main arm cylinder upward end limit switch (LS-3) stays OFF.
- 101 ... Main arm cylinder upward end limit switch (LS-3) stays ON.
- 102 ... Main arm cylinder downward end limit switch (LS-11) stays OFF.
- 103 ... Kick backward end limit switch (LS-6) stays OFF.
- 104 ... Kick backward end limit switch (LS-6) stays ON.
- 105 ... Wrist return end limit switch (LS-8) stays OFF.
- 106 ... Wrist return end limit switch (LS-8) stays ON.
- 107 ... Wrist flip end limit switch (LS-10) stays OFF.
- 110 ... Traverse outward end limit switch (LS-1) stays OFF.
- 111 ... Traverse inward end limit switch (LS-2) stays OFF..
- 112 ... Traverse inward end limit switch (LS-2) stays ON.
- 113 ... LS-9 stays ON on the traverse outward movement.
- 114 ... LS-9 stays OFF on the traverse inward movement.
- 115 ... Molded parts are not verified by LS-4, 5, Vacuum differential switch, LS-14 or etc.
- 116 ... Slide downward end limit switch for slide type external degating unit stays OFF, when it is in use.
- 117 ... Slide upward end limit switch for slide type external degating unit stays OFF, when it is in use.
  
- 555 ... External equipment ( injection machine etc. ) emergency stop switch is pressed.
- 666 ... Robot emergency stop switch is pressed.
- 777 ... Robot malfunction other than above 100-117.

When automatic cycle operation stops unexpectedly and the delay time set by T17 is up, the alarm number will be displayed on TROUBLE INDICATOR. Press RESET push button switch nearby the TROUBLE INDICATOR when the repairing work is finished.

## 2. Delay Timer Arrangements

Sixteen points on-delay type analogue timers are built in the 'sequencer' which is located on the back of front door and can be set to (0.1 to 1 sec) x magnification by volume. (Setting time is large by turning to the right.)

The change-over setting of magnification is made by changing over two switches per each timer as following table.

| Change-Over Switch |     | Magnification | Time of timer (sec) |     |
|--------------------|-----|---------------|---------------------|-----|
| SW1                | SW2 |               |                     |     |
| OFF                | OFF | 1             | 0.1                 | 1   |
| ON                 | OFF | 10            | 1                   | 10  |
| OFF                | ON  | 60            | 6                   | 60  |
| ON                 | ON  | 600           | 60                  | 600 |

### Functions of each timer

- T00 - To set the time delay after releasing traverse lock cylinder up to start the motor driving for the traverse movement. (approx. 0.5 sec.)
- T01 - To set the time delay after MOLD OPEN complete up to start the first descent (downward movement) of main (& sub) cylinder arm.
- T02 - To set the time delay after main (& sub) cylinder reaching the downward end (LS-11 is turned ON) up to start KICK forward.
- T03 - To set the time delay after main (& sub) cylinder reaching the downward end (LS-11 is turned ON) up to start gripping.
- T04 - To set the time delay after gripping the molding(s) up to start KICK backward.
- T05 - To set the time delay after main cyl. KICK backward to the end (LS-6 is turned ON) up to start the first ascent (upward movement).
- T06 - To set the time delay after detecting traverse outward end position and chuck positioning horizontal up to start second descent of main cyl.
- T07 - To set the time delay after detecting the downward end position of main cyl. arm up to actuate grip release.
- T10 - To set the time delay after actuating grip release up to start the second ascent of main cyl. arm. (upward movement)
- T11 - Aux. for option
- T12 - Aux. for option
- T13 - Aux. for option
- T14 - Aux. for option
- T15 - Aux. for option
- T16 - Aux. for option
- T17 - Total time delay for one cycle operation.

T I M E R

|                                      |   |                                     |   |
|--------------------------------------|---|-------------------------------------|---|
| TRAVERSE<br>START DELAY 00           | ○ | MAIN CYL. SECOND<br>ASCENT DELAY 10 | ○ |
| MAIN CYL. FIRST<br>DESCENT DELAY 01  | ○ | (OPTION) 11                         | ○ |
| KICK FORWARD<br>DELAY 02             | ○ | (OPTION) 12                         | ○ |
| GRIP TIMING<br>DELAY 03              | ○ | (OPTION) 13                         | ○ |
| KICK BACKWARD<br>DELAY 04            | ○ | (OPTION) 14                         | ○ |
| MAIN CYL. FIRST<br>ASCENT DELAY 05   | ○ | (OPTION) 15                         | ○ |
| MAIN CYL. SECOND<br>DESCENT DELAY 06 | ○ | (OPTION) 16                         | ○ |
| GRIP RELEASE<br>TIMING DELAY 07      | ○ | TROUBLE ALARM<br>TIMING DELAY 17    | ○ |

### Hard Wired Circuit Panel Designation of Components


1. Circuit Protector (Interruptor)
2. Power Transformer
3. Capacitor for 24V DC circuit
4. Capacitor for motor
5. Rectifier for Sequencer (24V DC)
6. Resistors (10 ohm, 20 watt)
7. Rectifier & Stabilizer for displays (Miniture Lamps & LEDs)
8. Noise Filter
9. Motor control pack.
10. Relays for Interface & Safety Circuit
  - RY1 Mold Open complete
  - RY2 Alarm output
  - RY3 Traverse speed slow-down
  - RY4 Traverse motor normal rotation
  - RY5 Traverse motor reverse
  - RY6 Traverse motor RUN/STOP
  - RY7 Robot emergency stop
  - RY8 Mold Close START
  - RY9 Mold OPEN/CLOSE Interlock
  - RY10 Knock-out Ejector START
  - RY11 I/M emergency stop
  - RY12 AUX. for option
  - RY13 AUX. for option
  - RY14-1/2 Main (& Sub) arm cyl. upward end position
  - RY15 Traverse outward end position
  - RY16 Traverse inward end position
  - RY17 AUX. for option
  - RY18 AUX. for option
  - RY19 AUX. for option
  - RY20 Main (& Sub) arm cyl. Descent Safety
  - RY21 AUX. for option
  - RY22 AUX. for option
  - RY23 AUX. for option

#### Remarks :

1. Put a relay having the corresponding coil voltage to the signal for Mold Open complete.
2. RY11 to TY13 are auxiliary relays for input from external coil voltage.
3. TY14 to RY20 are the relays of fixed safety circuit.
4. RY21 to RY23 are auxiliary relays for output of dry(zero-voltage) and A-contact signal.




CONTROL PANEL




CONTROL PANEL

ROBOT MODE ON SETTING

EMERGENCY STOP





**SWITCHES AND PILOT LAMP ARRANGEMENT**





X: Input  
Y: Output

CIRCUIT CONTROL ARRANGEMENT



CONNECTORS




- 1 48P connector (Input and Output for robot) CON.3
- 2 3 core cable for power supply
- 3 16 core interface cable between injection machine and robot
- 4 5P connector for motor (HFM series robot) CON.4
- 5 Option
- 6 Option



MITSUBISHI ONE BOARD SEQUENCER

MODEL PM-314C

A. DESIGNATION OF EACH PART



- |   |   |
|---|---|
| 1 External input-output joining connector | 11 Monitor joining connector                          |
| 2 D.C. 24V power supply terminal          | 12 Input-output indicating lamp                       |
| 3 Earth terminal                          | 13 Step-hold signal input terminal                    |
| 4 RUN contact output terminal             | 14 Cover  |
| 5 Parity error indicating lamp            | 15 Step hold signal input indicating lamp             |
| 6 Watch dog timer error indicating lamp   | 16 Battery back-up change-over connector              |
| 7 PROM-IC socket                          | 17 Battery  |
| 8 Timer time setting volume               | 18 Connection for timer output or digital code output |
| 9 Timer indicating lamp                   | 19 Digital code output indicating lamp                |
| 10 Timer magnification change-over switch | 20 D.C. 24V power supply indicating lamp              |




## B. DESCRIPTION FOR EACH PART

- 1) External input-output joining connector  
External 32 input wires, 24 output wires and common wires to input-output are connected by a connector with 72 poles. Refer to the item 11 for the arrangement of terminals. 0.3 to 0.75mm<sup>2</sup> diameter of electric wire is suitable for connecting with pole of connector by soldering.
- 2) DC24V power supply terminal  
This is the power supplying terminal of the sequencer.
- 3) Earth terminal  
Where grounding is made, make the grounding works of the third kind (less than 100 ohm, grounding resistance) and wire to the earthing terminal, E.A thunder surge remedy circuit is connected to the FE terminal, so the grounding is recommended (Connect short bar between E and EF.)
- 4) Terminal for RUN contact output  
This is a contact signal which informs consumers whether or not the sequencer is normally operated. The contact makes during normal operation. When abnormality is arisen at the sequencer or when supply voltage is lowered (DC12V) or when the power of the sequencer is turned off, the contact is broken.  
Contact capacity .... AC125V, 3A (Resistance load),  
1.5A (Inductive load  $\cos\phi=0.4$ )  
DC24V, 3A (Resistance load),  
1.5A (Inductive load L R=7ms)
- 5) Parity error indicating lamp  
When error is derived at the data in a PROM (trouble and others of PROM), the indicating lamp is lighted. In this case, a RUN contact is broken.
- 6) Watch dog timer indicating lamp  
Where the operation of the sequencer is stopped, the indicating lamp is lighted. Also in this case, the RUN contact is broken.

7) P-ROM IC socket

This is a socket where P-ROM IC is inserted. The P-ROM IC must be loaded and unloaded after shutting off the power and raising the lever of the socket to the vertical position, but in this case, use care not to bend the pin of IC and use care to the direction of the notch of IC. IC is damaged at the closing of the power supply when the P-ROM IC is inserted in the opposite way. In addition, bond a light interrupting tape to the erasing window of P-ROM IC.

Having two sockets, insert P-ROM IC to P-ROM-1, P-ROM-2 sockets in order to the program.



8) Timer time setting volume

Sixteen points on-delay type analogue timers built in the sequencer can be set (Setting time is large by turning to the right) to (0.1 to 1sec) x magnification by volume.


9) Timer indicating lamp

The indicating lamp is lighted, when time is up.

10) Timer magnification change-over switch

This is switch for setting the magnification (1.10.60.600) of a timer. The change-over setting of magnification is made by changing over two switches per each timer. The change-over setting of magnification should be in accordance with the following table.


| Change-over switch |     | Magnification | Time of timer<br>(sec) |
|--------------------|-----|---------------|------------------------|
| SW1                | SW2 |               |                        |
| OFF                | OFF | 1             | 0.1 ~ 1                |
| ON                 | OFF | 10            | 1 ~ 10                 |
| OFF                | ON  | 60            | 6 ~ 60                 |
| ON                 | ON  | 600           | 60 ~ 600               |



- 11) Monitor connecting connector  
This is a connector for connecting on-line monitor PM-305M. It is no use under normally operation.
- 12) Input-output indicating lamp  
This is a light emitting diode indicating the state of an input-output signal and is lighted when the input-output signal is turned ON.
- 13) Step-hold signal input terminal  
These terminals are utilized in the case of a control unit which requires make an automatic continuous operation withstanding instantaneous or continuous power failure.
- 14) Cover  
This is the cover of a sequencer. This indicating part forms a window produced by acrylic resin so that a display lamp can be seen. The number of an input-output timer and digital cor are silk screened on the side of the acrylic window. Removed the cover during the loading and unloading of P-ROM.
- 15) Step hold signal input indicating lamp  
This lamp is lighted up, when the space between C and D of step hold signal terminals is OFF (continuity is interrupted).

16) Battery back-up change-over connector

Shift a short pin to the side of M.B (memory back-up) only when the battery back-up (holding of temporary storage at power failure) is needed. A number of temporary storage (memory) where battery back-up is available has 128 items from 600 to 777.



17) Battery (GB350 made by GS)

The battery is required in the battery back-up of a memory. It holds the contents of the memory (M600 to M777) for about 100 days even during the without power. Where the battery is left as it is for more than 100 days, it can be fully charged when the power of the sequencer is turned on for about one day at the state where an input-output connector is removed. In addition, where the battery back-up becomes unnecessary, shift the short pin to the non-M.B. side with the battery loaded.

18) Connection for timer output or digital code output

This is a connector for external output of 6 items of timers (T00 to T05) or 10 items of digital codes.

It is unnecessary to use this connector where the timers or the digital codes are not output to the exterior.

19) Digital code output indicating lamp

This lamp is lighted up, when digital code output is ON.

20) D.C. 24V power supply display lamp

This lamp is lighted up when the power is supplied to the sequencer.

OPTIONAL PROGRAM

(10) NIPPER CUT TIMING

0. OFF

1. POSITIONING HORIZONTAL (Nipper on chuck)

2. SECOND DESCENT ( " )

3. WITHOUT SLIDING (External degating unit)

4. SLIDING ( " )

### OPTIONAL TIMER

- T11 - To set the time delay after traverse outward end limit switch is pressed up to external nipper ON.
- T12 - To set the time delay after external nipper ON up to nipper OFF
- T13 - To set the time delay after external nipper OFF up to main cylinder arm kick backward
- T14 - To set the time delay after detecting position of external degating unit downward end up to external nipper ON
- T15 - To set the time daly after external nipper ON up to nipper OFF
- T16 - To set the time delay after external nipper OFF up to main cylinder arm kick beckward

---

Conair has made the largest investment in customer support in the plastics industry. Our service experts are available to help with any problem you might have installing and operating your equipment. Your Conair sales representative also can help analyze the nature of your problem, assuring that it did not result from misapplication or improper use.

## WE'RE HERE TO HELP

To contact Customer Service personnel, call:



## HOW TO CONTACT CUSTOMER SERVICE

**From outside the United States, call: 814-437-6861**

You can commission Conair service personnel to provide on-site service by contacting the Customer Service Department. Standard rates include an on-site hourly rate, with a one-day minimum plus expenses.

### **If you do have a problem, please complete the following checklist before calling Conair:**

- Make sure you have all model, serial and parts list numbers for your particular equipment. Service personnel will need this information to assist you.
- Make sure power is supplied to the equipment.
- Make sure that all connectors and wires within and between loading control and related components have been installed correctly.
- Check the troubleshooting guide of this manual for a solution.
- Thoroughly examine the instruction manual(s) for associated equipment, especially controls. Each manual may have its own troubleshooting guide to help you.
- Check that the equipment has been operated as described in this manual.
- Check accompanying schematic drawings for information on special considerations.

## BEFORE YOU CALL ...

*Additional manuals and prints for your Conair equipment may be ordered through the Customer Service or Parts Departments for a nominal fee.*

---

## EQUIPMENT GUARANTEE

Conair guarantees the machinery and equipment on this order, for a period as defined in the quotation from date of shipment, against defects in material and workmanship under the normal use and service for which it was recommended (except for parts that are typically replaced after normal usage, such as filters, liner plates, etc.). Conair's guarantee is limited to replacing, at our option, the part or parts determined by us to be defective after examination. The customer assumes the cost of transportation of the part or parts to and from the factory.

## PERFORMANCE WARRANTY

Conair warrants that this equipment will perform at or above the ratings stated in specific quotations covering the equipment or as detailed in engineering specifications, provided the equipment is applied, installed, operated and maintained in the recommended manner as outlined in our quotation or specifications.

Should performance not meet warranted levels, Conair at its discretion will exercise one of the following options:


- Inspect the equipment and perform alterations or adjustments to satisfy performance claims. (Charges for such inspections and corrections will be waived unless failure to meet warranty is due to misapplication, improper installation, poor maintenance practices or improper operation.)
- Replace the original equipment with other Conair equipment that will meet original performance claims at no extra cost to the customer.
- Refund the invoiced cost to the customer. Credit is subject to prior notice by the customer at which time a Return Goods Authorization Number (RGA) will be issued by Conair's Service Department. Returned equipment must be well crated and in proper operating condition, including all parts. Returns must be prepaid.


Purchaser must notify Conair in writing of any claim and provide a customer receipt and other evidence that a claim is being made.

## WARRANTY LIMITATIONS

**Except for the Equipment Guarantee and Performance Warranty stated above, Conair disclaims all other warranties with respect to the equipment, express or implied, arising by operation of law, course of dealing, usage of trade or otherwise, including but not limited to the implied warranties of merchantability and fitness for a particular purpose.**

CABLE CONNECTION BETWEEN ROBOT & INJECTION MACHINE






1 2 3 4 5 6 7 8

SCHEMATIC DIAGRAM  
HFM-00 1-7 49

TB-1



Injection machine  
emergency stop  
signal input

Aux. Input


37

38


Aux. Input

39

40




GATE



AUTO

\* When the injection machine emergency stop signal is applied to control box, please disconnect these wires (cord No. 300 & 9).

|    |   |   |     |    |    |   |
|----|---|---|-----|----|----|---|
|    |   |   | 設計  | 検査 | 承認 |   |
|    |   |   |     |    |    |   |
|    |   |   |     |    |    |   |
| 訂正 | 来 | 歴 | 年月日 |    |    | 1 |




MS3102A 14-55  
 MS3106B 14-5P  
 MS3057-6A

|     |        |    |      |       |                           |
|-----|--------|----|------|-------|---------------------------|
| REV | DATE   | BY | CHKD | APP'D | DESCRIPTION               |
| 1   | 1988.9 |    |      |       | C20 核 查 定 RY7 拆 去 九 号 脚 踪 |
| 2   | 1988.9 |    |      |       | 修 110                     |

SCHMATIC DIAGRAM  
 HFM Series


HERMANCO



|           |         |    |     |
|-----------|---------|----|-----|
| 図号        | PC-1    | 図番 |     |
| 名称        | モーター回路図 |    | 尺取  |
| 検図        |         |    | 1/1 |
| 株式会社 JI-2 |         |    |     |








SCHEMATIC DIAGRAM

HFM-600 2-11-70-32

1-33

4




| CON. 0 | Component | Description                                  |
|--------|-----------|--|
| N      | X 26      | Manual Operation of Chuck tilting horizontal |
| 12     | 27        | Manual Operation of Chuck tilting vertical   |
| P      | 30        | Manual Operation of Traverse outward         |
| 13     | 31        | Manual Operation of Traverse inward          |
| R      | 32        | Option Selector 1                            |
| 14     | 33        | Option Selector 2                            |
| S      | 34        | Option Selector 3                            |
| 15     | 35        | Option Selector 4                            |
| T      | 36        |  |
| 16     | 37        |  |
| U      |           |  |
| 17     | DC24V (-) |  |
| V      | COMMON    |  |
| 18     |           |  |
| W      |           |  |
| 19     |           |  |

SCHEMATIC DIAGRAM  
 HFM-600 2-11-72-AB

5/







SCHEMATIC DIAGRAM  
HEM - 600 2-1-X-1 板



