

USERGUIDE

June 1995

KG-200 Controller Series

HIM Series Robot

HE Series Robot



WARNING - Reliance on this Manual Could Result in Severe Bodily Injury or Death!

This manual is out-of-date and is provided only for its technical information, data and capacities. Portions of this manual detailing procedures or precautions in the operation, inspection, maintenance and repair of the product forming the subject matter of this manual may be inadequate, inaccurate, and/or incomplete and cannot be used, followed, or relied upon. Contact Conair at info@conairgroup.com or 1-800-654-6661 for more current information, warnings, and materials about more recent product manuals containing warnings, information, precautions, and procedures that may be more adequate than those contained in this out-of-date manual.

CONTENTS

1.	FEATURES	1
2.	CAUTION ON HANDLING KG-200 SRS.CONTROLLERS..	2
3.	STANDARD SPECIFICATION	3
4.	CONTROL BOX	6
5.	TURN THE POWER ON	8
6.	OPERATION MODE	8
7.	BASIC MOTION SEQUENCE	10
8.	INITIAL SETTING	12
9.	MANUAL OPERATION	15
10.	AUTO OPERATION	16
11.	MODE SELECTION	18
12.	TIMER SETTING	19
13.	INPUT/OUTPUT STATUS	24
14.	COUNTER	25
15.	MODE SETTING	26
16.	POSITION SETTING ON TRAVERSE BEAM	33
17.	MULTI-ROW PLACING ON THE TRAVERSE BEAM	37
18.	PROGRAM STORAGE.....	40
19.	MECHANICAL MAIN/SUB STRIP STROKE ADJUSTMENT	43
20.	MECHANICAL MAIN/SUB VERTICAL STROKE ADJUSTMENT..	46
21.	ERROR DISPLAY	48
	ERROR MESSAGE.....	49
22.	INTERFACE BETWEEN THE ROBOT AND PRESS.....	64

1. FEATURES

The KG controller controls the HIM/HE series robot with its sequence control system which is applicable for complicated special robot motion. It is available to control the robot operation just besides the robot by using a handy console.

- MODE SELECTION Selection of [ROBOT OFF] , [AUTO MODE] and [PGM·MAN] by a key switch.
- EMERGENCY STOP Cut off the all output by pressing EMERGENCY STOP switch.
- MANUAL OPERATION Individual manual operation of Main arm, Strip, traverse and wrist flip motion are available.
- RETURN TO HOME..... Possible to return to home position by [HOME] button.
- SETTING MODE setting and TIMER setting are done with digital display.

The following display is available on the LCD (Liquid crystal display with back light) which has 16 letters and 4 lines.

- PROGRAM NUMBER Max. 20 programs can be stored
- MODE setting Setting of operation mode
- TIMER setting Digital display and setting of timer value (units of 0.01SEC)
- X AXIS POSITION Digital display and setting of X axis stop position
- PALLETIZING Setting of stop pitch and number (Multi-row placing) of stops
- INPUT/OUTPUT display ... Monitoring of I/O status (Robot I/O and interface with press)

POSITION ON X AXIS Display of the present position
on the traverse beam

ALARM indication Diagnosis of handling problem

ERROR message Error messages of robot problem

COUNTER Cycle counter of robot operation
and take out cycle

2. CAUTION ON HANDLING KG-200 CONTROLLER

Make sure the followings before operate the robot with KG controller.

- 1) Press the keys on control panel by finger. Do not press the keys by sharp shaped tool such as screw driver in order to protect keys from being damaged.
- 2) Make sure that the circuit breaker is OFF when connect and disconnect the cables of KG controller.
- 3) Check if the wiring (interface between the press and robot) is correct after installation of robot. The miss wiring might cause the miss operation or damage the controller or robot.
- 4) Keep the controller in the proper position. Especially, high temperature and/or vibration will cause the problem.

3. STANDARD SPECIFICATION

a) Conditions

	Specification
Power supply	AC 200V 50/60 Hz Three phase
Allowable voltage	AC 180V ~ AC 253V
Allowable frequency range	$\pm 5\%$
Power consumption	650 Watt (Max) (KG-201/204) 1130 Watt (Max) (KG-203)
Temperature range	0°C ~ + 50°C
Humidity range	35% ~ 85% RH, No dew
Circumstance	No corrosion gas and dust

b) Control

	Specification
Control system	Stored program system
Programming system	ROM fixed sequence program
Program capacity	8000 Steps
Scan speed	0.74 μ s
Program protection	Pass word
Battery life time	3 years(+5° ~+35°) Lithium bat.
Temperature range	0°C ~ + 55°C
Humidity range	35% ~ 85% RH, No dew
Voltage resistance	AC 1500V / 1 min.
Insulation resistance	Over 5M Ω at DC 500V
Circumstance	No corrosion gas and dust

c) Input/Output

	Specification
Input	DC 24V 7 A (Open collector)
Transistor output(Max)	DC 24V 200 mA (Open collector)
Relay output	AC 250V, DC 30V 5A
Insulation	Photo-coupler

d) Power supply for control circuit

	Specification
Power supply	AC 200V 50/60 Hz Single phase
Allowable voltage	AC 170V ~ AC 264V
Voltage resistance	AC 2KV / 1 min. (Cut off 20mA)
Temperature range	0° C ~ + 50° C
Humidity range	30% ~ 90% RH, No dew
Preservation temp.	-20° C ~ + 85° C (20% ~ 95%)
Over load protection	Over 105% of rated consumption
Safety standard	UL1012, CSA EB1402

e) Inverter.

	Specification
Power supply	AC200V ~ AC230V 50/60HZ 3phase
Allowable voltage range	AC 180V ~ AC 253V(50/60 HZ)
Allowable frequency range	± 5%
Power capacity	1.5KVA (0.4kw)(KG-201/204) 4.5KVA (1.5kw)(KG-203)
Rated output	1.2KVA (0.4kw)(KG-201/204) 3.2KVA (1.5kw)(KG-203)
Temperature range	- 10° C ~ + 50° C
Humidity range	90% RH, No dew
Preservation temp.	-20° C ~ + 65° C
Protection	Over current, Over load, External thermal protection
Power consumption	Less 4.3A (1.4Kw) Less 7.2A (0.75Kw)

4. CONTROL BOX.

1 SWITCH PANEL ON THE BOX

(1) [KEY SWITCH]


- a) ROBOT OFF .. For the operation of only the press (without the robot).
- b) AUTO MODE .. For the auto operation of the robot.
- c) PGM·MAN (Program and manual)
.. For the setting of the MODE, TIMER, and STOP POSITION, and for MANUAL OPERATION.

(2) [EMERGENCY STOP]

The robot stops immediately when this switch is pressed.

(3) [POWER]

The switch enable the drive circuit live.



(4) [ROBOT READY]

Perform the initialization of motor drive circuit.
After robot ready is performed, each actuator can be actuated.

(5) [AUTO START]

The robot starts auto operation.

(6) [AUTO STOP]

The robot stops at its cycle end position.

5. TURN THE POWER ON

- 1) After checking the correct interface with press, turn the circuit breaker in the controller ON.
- 2) After turning the power ON, the controller will have an Initial check.(self diagnosis) and display the message as below.

ROBOT CONTROLLER
HANDY CONSOLE
(C) COPYRIGHT
VER 12 ··HARMO

Note) VER 12 indicates the ROM version

- 3) Operation mode indication is shown after initial check (2 seconds later) on the LCD display.

6. OPERATION MODE


The selection of following three modes is available by the key switch. High reliability and safety are obtained by not only the program stored in ROM IC but also external hardware circuit.

1) ROBOT OFF mode

When the key switch is set to [ROBOT OFF], the following message is shown on the LCD. Under this mode, the interlock signals for the press are released and press operation is available without robot.

ROBOT OFF MODE

INTERLOCK
RELEASED




Note) If the robot is not at home position the interlock for the press is effective.

2) AUTO mode

When the key switch is set to [AUTO MODE], the following message will appear on the LCD and the robot AUTO operation is available.

ROBOT AUTO MODE
PRESS AUTO START




See for (10) auto operation.

3) PGM-MAN (Program and manual) mode


When the key switch is set to [PGM MAN], the following message will appear on the LCD. The each setting (Program #, Modes, Timer value, Positions on the beam etc.) and manual operation by pressing MANUAL key are available.

INITIALIZE
HOME, RETURN
UNDER MANUAL
MODE



See for (9) manual operation.

7. BASIC MOTION SEQUENCE



- | | |
|----------------------|---------------------------|
| 1. Arm first descent | 7. Wrist flip horizontal |
| 2. Strip forward | 8. Arm second descent |
| 3. Grip | 9. Release |
| 4. Strip backward | 10. Arm second ascent |
| 5. Arm first ascent | 11. Wrist return vertical |
| 6. Traverse outward | 12. Traverse inward |



The above motion sequence is obtained by the following mode setting.

M1: Pick up arm select	MAIN
M2: Part grip select	WITH SWITCH
M4: Part release position	2ND.DESC MID MOLD
M5: Main sprue grip select ...	OFF
M9: Wrist motion	OUT TRAVERSE

HARMO DATA PRG.

DP-201

非常停止
EMERGENCY STOP



MODE +	MODE -	MAN.	HOME	MAN. OPT
U P OPT1	FWD OPT3	OUT OPT5	VERT OPT7	GRIP OPT9
DOWN OPT2	BWD OPT4	I N OPT6	HORZ OPT8	REL OPT10
ARM ADJ	MAIN +	SUB +	JOG SLOW	PGM CALL
STEP ADJ	MAIN -	SUB -	JOG FAST	PGM SAVE
No. ▽	ITEM ◀	INCR △	UNIT 10	SET
No. △	ITEM ▶	DECR ▽	UNIT 1	CLR

8. INITIAL SETTING


Initial setting of positions on traverse beam is needed when installed and change the program number.

1 MECHANICAL HOME POSITION

Set mechanical home position first.

- 1) Turn the key switch to [PGM-MAN].
- 2) Press [POWER] and confirm the white lamp lights.

```
*INITILIZE*
PRESS
[POWER]
```



- 3) Press [ROBOT READT], then yellow lamp blinks and start to run.

```
*INITILIZE*
PRESS
[ROBOT READY]
```

- 4) Robot go out to the traverse outward end and return to the main second descent safety off position, then stop when it becomes off. The indication is shown as below.

```
*INITILIZE*
SET THE
POSITION [PO]
BY TEACHING
```

- 5) Press [MODE +] / [MODE -] to call the LCD message as shown below.

```
*TEACHING DATA*
HOME POSITION
PO=±***PS=- 000
SPEED=.....LOW
```

6) Press [IN] continuously. the robot return to home position at that time.

NOTE) "HIGH" or "LOW" is indicated in the right lower part on the LCD.
press [JOG FAST]robot return to fast
press [JOG LOW]robot return to slow

7) Pressing the button until robot return to the return limit actuator proximity switch position(L-X1) and release the switch.

NOTE) please do not press the switch continuously after that cause of over run.

8) Press [SET] .
The indication is shown as below.

```
*TEACHING DATA*
HOME POSITION
PO=  0  PS=  0
SPEED=  1
```

Home position above the mold is completed.

NOTE) Press [INCR Δ]/[DECR ▼] the speed at the button of LCD change to 1. 2. 3. 4. 5.

```
*TEACHING DATA*
HOME POSITION
PO=  0  PS=  0
SPEED=  1
```

>>>>>>>>

```
*TEACHING DATA*
HOME POSITION
PO=  0  PS=  0
SPEED=  2
```

9) Press [NO ▽]/[NO Δ] the LCD display change to as shown below.

TEACHING DATA
HOME POSITION
PO=±****PS=±****
SPEED=.....

TEACHING DATA
WAITING NIPPER
P3=±****PS=±****
SPEED=.....

TEACHING DATA
PART RELEASE
P1=±****PS=±****
SPEED=.....

TEACHING DATA
OP1 POSITION
P4=±****PS=±****
SPEED=.....

TEACHING DATA
SPRUE RELEASE
P2=±****PS=±****
SPEED=.....

TEACHING DATA
OP2 POSITION
P5=±****PS=±****
SPEED=.....


9. MANUAL OPERATION

MANUAL operation and HOME RETURN operation can be done under MANUAL OPERATION MODE. The manual operation outside the mold area is available even if the mold open complete signal is OFF.

MANUAL OPERATION

- 1) Turn the key switch to [PGM·MAN].
- 2) Press [MAN]. [AUTO START] switch is blinks with green light press each manual button and operate manually refer to item (3)
if press [MAN] again, the green lamp goes out and the manual operation becomes not effective.
- 3) RETURN TO HOME POSITION
While the green lamp lights under auto mode, the robot returns to home position automatically by pressing [HOME].
- 4) The functions of each manual button are as follows.

[UP].....Arm ascent
[DOWN].....Arm descent
[FWD].....Arm strip forward
[BWD].....Arm strip backward
[OUT].....Traverse outward
[IN].....Traverse inward
[VERT].....Wrist return vertical
[HORZ].....Wrist flip horizontal
[GRIP].....Grip on and Nipper on(nipper position)
[REL].....Grip off



10. AUTO OPERATION


1) Turn the key switch to [PGM.MAN]

2) Press [POWER], then white lamp lights.

3) Press [ROBOT READY], then yellow lamp blinks and mechanical home position initial setting is performed.

4) When [ROBOT READY] sequence is finished, the indication is shown as below.

MANUAL MODE
RETURNED TO
HOME POSITION



5) Return the robot to home position by pressing [HOME] or [IN].

6) Turn the key switch to [AUTO MODE]

7) Check the following message is shown on the LCD. and press [AUTO START]. the robot starts auto operation.

*ROBOT AUTO MODE
PRESS AUTO START

8) If the part verification is ON after take out motion, the controller issue the safety interlock release and mold closing start signal to the press. The robot starts to traverse out.

9) If the part verification is OFF, alarm sounds and green lamp blinks.

- 10) Press [AUTO START] button after make sure that nothing is remained in the mold area.
The robot and press continue to next sequence.
- 11) After returned to home position, the robot waits for the next mold open complete signal.
- 12) To stop the AUTO OPERATION, press [AUTO STOP], then the [AUTO START] lamp blinks.
When returned to home position, the AUTO OPERATION stops.


Note) To start AUTO OPERATION is available only when the robot is at home position.

- 13) If needed to stop the robot immediately, then the key switch to [ROBOT OFF] or [PGM-MAN], when the AUTO OPERATION stop. and press EMERGENCY STOP switch.
- 14) Mode setting during AUTO operation is not available, but timer setting can be done. Refer to the instruction "TIMER SETTING".


11. MODE SELECTION

Press [MODE +]/[MODE -] button to select the each mode.

1) AUTO OPERATION :



2) MANUAL OPERATION




12. TIMER SETTING

Set timer value in order to have secure take out motion and minimize the take out time.

Timer setting range is from 0.00sec. to 9.99sec..

Timer setting is available not only under manual mode but also during auto operation.



SETTING



- 1) Turn the key switch to [PGM・MAN] or [AUTO MODE]
- 2) Press [MODE+] or [MODE-] to call the LCD message as shown below.

TIMER SET
 FIRST DESC DLY
 T01= . SEC

- 3) Select timer T01 through T20 by [NoΔ]/[No∇] ,
- 4) Select time unit by [INCR Δ]/[DECR ∇] .



[UNIT 10] ...To increase/decrease value in
0.1 units.

[UNIT 1] ...To increase/decrease value in
0.01 units

* [UNIT 10]/[UNIT 1] should be pressed before
[INCRΔ]/[DECR∇] pressed.

TIMER SETTING

Preset timer value T01 to T08, T09 to T16 and T17 to T24 can be seen on the LCD. And the timer setting is available on the same page.

TIMER SET
FIRST DESC DLY
T01=_.__SEC

From mold open complete up to arm first descent.

TIMER SET
STRIP FWD DLY
T02=_.__SEC

From arm descent up to strip forward.

TIMER SET
PART GRIP DLY
T03=_.__SEC

From strip forward up to grip.

TIMER SET
STRIP BWD DLY
T04=_.__SEC

From grip up to strip backward.

TIMER SET
FIRST ASC DLY
T05=_.__SEC

From strip backward up to arm first ascent.

TIMER SET
SECOND DESC DLY
T06=_.__SEC

From traverse outward end up to second descent.

TIMER SETTING

Preset timer value T01 to T08, T09 to T16 and T17 to T24 can be seen on the LCD. And the timer setting is available on the same page.

TIMER SET
FIRST DESC DLY
T01=_.__SEC

From mold open complete up to arm first descent.

TIMER SET
STRIP FWD DLY
T02=_.__SEC

From arm descent up to strip forward.

TIMER SET
PART GRIP DLY
T03=_.__SEC

From strip forward up to grip.

TIMER SET
STRIP BWD DLY
T04=_.__SEC

From grip up to strip backward.

TIMER SET
FIRST ASC DLY
T05=_.__SEC

From strip backward up to arm first ascent.

TIMER SET
SECOND DESC DLY
T06=_.__SEC

From traverse outward end up to second descent.

TIMER SET
PART RELEASE DLY
T07=_.__SEC

From arm second descent up to
part release.

TIMER SET
SECOND ASC DLY
T08=_.__SEC

From grip release up to arm second
ascent.

TIMER SET
SPRUE REL DLY
T09=_.__SEC

From sprue release position to
sprue release.

TIMER SET
EJECTOR FWD DLY
T10=_.__SEC

From mold open complete up to
ejector forward.

TIMER SET
NIPPER CUT TIME
T11=_.__SEC

From nipper cut on time.

TIMER SET
NIPPER APPR DLY
T12=_.__SEC

From waiting nipper approach.

TIMER SET
WTG NIP ON DLY
T13=_.__SEC

From waiting nipper approach to
nipper cut.

TIMER SET
WTG NIP OFF DLY
T14=_.__SEC

From waiting nipper cut to nipper
off.

TIMER SET
WTG NIP BWD TIME
T15=_.__SEC

From waiting nipper off to retract.

TIMER SET
OPTION TIMER 1
T16=_.__SEC

For option.

TIMER SET
OPTION TIMER 2
T17=_.__SEC

For option.

TIMER SET
OPTION TIMER 3
T18=_.__SEC

For option.

TIMER SET
OPTION TIMER 4
T19=_.__SEC

For option.

TIMER SET
OPTION TIMER 5
T20=_.__SEC


For option.

13. INPUT/OUTPUT STATUS

This controller has a function to check the status of INPUT/OUTPUT of the robot and interfacing with external device (press etc.) on the LCD.

(1) DISPLAY THE I/O STATUS

1. Turn the key switch to [PGM·MAN] or [AUTO MODE].
2. Press [MODE+] or [MODE-], to call the LCD message as shown below.



The followings are the meaning for some I/O status symbols.

See attached INPUT/OUTPUT list for more details.

INPUT	
ES	EMERGENCY STOP
EX	EXTERNAL DEVICE
OP	PRESS OPTION
EJ	EJECTOR FWD. END
RS	REJECTED PARTS
AT	PRESS IN AUTO
DR	SAFETY DOOR CLOSED
MC	MOLD CLOSE COMPLETE
MO	MOLD OPEN COMPLETE

OUTPUT	
CV	CONVEYOR
OP	OPTION (EXTERNAL DEVICE)
BZ	BUZZER
AT	ROBOT AUTO
RD	ROBOT READY
PW	POWER
MC	MOLD CLOSE SAFETY
MO	MOLD OPEN SAFETY
ST	MOLD CLOSING SAFETY
EJ	EJECT TIMING
OP	PRESS OPTION

14. COUNTER

The total cycle counter of the robot and take out cycle is available.


COUNTER DISPLAY

- 1) Turn the key switch to [PGM·MAN] or [AUTO MODE].
- 2) Press [MODE+] or [MODE-] . to call the LCD message as shown below.

```
*COUNT*  
TAKE OUT T=.....  
CYCLE     C=.....
```

Note) The take out cycle counter can be cleared to " 0 " count by [CLR] button, but the robot cycle counter can not be cleared.

The count number of total cycle should be read as " INDICATING NUMBER ON LCD x 10000"
(e.g. T=xxx5 should be read 50,000 counts)



15. MODE SETTING

Set modes according to the following procedure.

Note) Mode setting is not available under AUTO OPERATION mode.

MODE SETTING

1) Turn the key switch to [PGM-MAN].

2) Press [MODE+] or [MODE-] to call the LCD message as shown below.

```
*MODE SET*
M1 PICK UP ARM
MAIN SUB M+S
MAIN+SUB
```

3) Select the page to change the mode by [NO Δ]/ [NO ▽].



```
*MODE SET*
M2 PART GRIP
OFF W/SW W/O SW
WITH SWITCH
```

4) Move the [ITEM ←]/[ITEM →] to change the message.

```
*MODE SET*
M2 PART GRIP
OFF W/SW W/O SW
OFF
```

5) Set data is stored in the memory.

6) Set other modes in the same manner.



MODE SELECTION

M1 PICK UP ARM

MODE SET
M1 PICK UP ARM
MAIN SUB M + S
~~MAIN + SUB~~

- 1) MAIN. ·Take out molding by main arm.
- 2) SUB. ·Take out sprue/runner by sub arm
- 3) M + S (MAIN + SUB)
·Take out molding and sprue/runner from 3 plate molds.

M2 PART GRIP

MODE SET
M2 PART GRIP
OFF W/SW W/O SW
~~WITH SWITCH~~

- 1) OFF ·Grip circuit not in use.
- 2) W/SW (WITH SWITCH)
·Use grip circuit with part verification switch.
- 3) W/O SW (W/O SWITCH)
·Use grip circuit without part verification.

M3 VACUUM

MODE SET
M3 PART VACUUM
OFF W/SW W/O SW
~~WITH SWITCH~~

- 1) OFF ·Vacuum circuit not in use.
- 2) W/SW (WITH SWITCH)
·Use vacuum circuit with vacuum differential switch.
- 3) W/O SW (W/O SWITCH)
·Use vacuum circuit without verification.

CAUTION ON GRIP CIRCUIT SELECT

In the following mode setting, the interlock signal for mold open/close cannot be released. please make the mode so to use any grip circuit.

M 1 (ARM) ····	MAIN	M 2 (PART GRIP) ····	OFF
M 3 (VACUUM)···	OFF	M 5 (M. SPRUE GRIP)··	OFF
M 7 (S. GRIP)··	OFF		

M4 PART RELEASE POSITION

MODE SET
M4 PART RELEASE
2 DESC WAY IN/MO
~~2DESC MID MOLD~~

- 1) 2 DESC (2DESC MID MOLD)
 - Release the molding at arm second descent end.
- 2) WAY (MID TRAVERSE)
 - Release the molding at traverse end without second descent.
- 3) IN/MO (IN MOLD)
 - Release the molding in the mold area after strip backward motion.

M5 MAIN SPRUE GRIP

MODE SET
M5 M. SPRUE GRIP
OFF W/SW W/O SW
~~WITH SWITCH~~

- 1) OFF
 - Main arm sprue grip circuit not in use.
- 2) W/SW (WITH SWITCH)
 - Use main sprue grip circuit with sprue verification switch.
- 3) W/O SW (WITHOUT SWITCH)
 - Use main sprue grip circuit without sprue verification switch.

M6 SPRUE RELEASE TIMING

MODE SET
M6 SPRUE REL
OUT IN MOLD
~~ON WAY OUT~~

- 1) OUT (ON WAY OUT)
 - Release sprue on way out of traverse before releasing the molding.
- 2) IN (ON WAY IN)
 - Release sprue on way in of traverse after releasing the molding.
- 3) MOLD (INMOLD AREA)
 - Release sprue after strip backward motion in the mold area.

M7 SUB GRIP

MODE SET
M7 SUB GRIP
OFF W/SW W/O SW
~~WITH SWITCH~~

- 1) OFF ·Grip circuit not in use.
- 2) W/SW (WITH SWITCH)
·Use grip circuit with part verification switch.
- 3) W/O SW (WITHOUT SWITCH)
·Use grip circuit without part verification switch.

M8 EJECTOR INTERLOCK RELEASE

MODE SET
M8 EJECTOR I/L
REL TIME SYNCHR
~~WITH TIMER~~

- 1) REL (RELEASED)
·Eject interlock is released when the timer that start counting at the same time of mold open complete signal goes ON.
(No interlocking)
- 2) TIME (WITH TIMER)
·Eject interlock is released when the timer that start counting at the same time of arm descent elapses.
- 3) SYNCHR (SYNCHRONIZED)
·Eject interlock is released when the arm reaches strip forward end position, and the end of arm tooling grips the molding when the ejector forward end signal goes ON.

M9 WRIST FLIP POSITION

MODE SET
M9 WRIST MOTION
OUT ABOVE OFF.
~~OUT TRAVERSE~~

- 1) OUT (OUT TRAVERSE)
·Wrist flip motion is done in the area of second descent safty zone.
- 2) ABOVE (ABOVE MOLD)
·Wrist flip motion is done at above mold.
- 3) OFF ·Without wrist flip motion.

M10 NIPPER CUT

MODE SET
M10 NIPPER CUT
OFF EOAT WTG E+W
ON EOAT

- 1) OFF ·Nipper circuit not in use
- 2) EOAT (ON EOAT)
·Nipper actuates at molding release position.
- 3) WTG (WAITING NIPPER)
·For external nipper station equipped in the area of second descent safety zone.
- 4) E+W (EOAT & WAITING)
·Use above 2)EOAT and 3) WTG together.

M11 REJECT PART RELEASE

MODE SET
M11 REJECT REL
OFF MID MOLD
MID TRAVERSE

- 1) OFF ·Reject part signal from the press is not effective.
- 2) MID (MID TRAVERSE)
·Release molding at sprue releasing position when the reject signal from the press is ON.
- 3) MOLD (IN MOLD)
·Release the molding in the mold area when the signal is ON.

M12 ROBOT HOME POSITION (OPTION)

MODE SET
M12 HOME
MOLD BEAM
ABOVE MOLD

- 1) MOLD (ABOVE MOLD)
·Robot waits for mold open at traverse inward end position (Above mold)
- 2) BEAM (ON BEAM)
·Robot waits at preset position on the beam and start when the mold open complete signal goes ON.

M13 WRIST ROTATION (OPTION)

MODE SET
M13 WRIST ROTATE
OFF IN USE
IN USE

- 1) USE ·Wrist rotate function in use.
- 2) OFF ·Wrist rotate function not in use.

M14 OPTION

MODE SET
M14 OPTION 1
OFF IN USE
IN USE

- 1) OFF ·Optional function 1 not in use.
- 2) IN USE ·Optional function 1 in use.

M15 OPTION

MODE SET
M15 OPTION 2
OFF IN USE
IN USE

- 1) OFF ·Optional function 2 not in use.
- 2) IN USE ·Optional function 2 in use.

M16 OPTION

MODE SET
M16 OPTION 3
OFF IN USE
IN USE

- 1) OFF ·Optional function 3 not in use.
- 2) IN USE ·Optional function 3 in use.

M17 OPTION

MODE SET
M17 OPTION 4
OFF IN USE
IN USE

- 1) OFF ·Optional function 4 not in use.
- 2) IN USE ·Optional function 4 in use.

M18 OPTION

MODE SET
M18 OPTION 5
OFF IN USE
~~IN USE~~

- 1) OFF ·Optional function 5 not in use.
- 2) IN USE ·Optional function 5 in use.

M19 MAIN TAKE OUT MOTION (OPTION)

MODE SET
M19 M.TAKE OUT
MOVABLE FIXED
~~MOVABLE~~

- 1) MOVABLE (MOVABLE MAIN ARM)
·Pick up from movable mold.
- 2) FIXED (FIXED MAIN ARM)
·Pick up from fixed mold.

M20 SUB TAKE OUT MOTION (OPTION)

MODE SET
M20 S. TAKE OUT
FIXED MOVABLE
~~FIXED~~

- 1) FIXED ·Sub arm pick up from fixed mold.
- 2) MOVABLE ·Sub arm pick up from movable mold.

16. POSITION SETTING ON TRAVERSE BEAM

When set up the robot or change the stop position such as take out position and part release position, It is very easy to set or change the positions.

SETTING

- 1) Turn the key switch to [PGM-MAN].
- 2) Press [MODE+]/[MODE-] to call the LCD message as shown below.

```
*TEACHING DATA*  
HOME POSITION  
PO.....PS.....  
SPEED.....
```


PS = PRESENT POSITION

PO = SET POSITION

NOTE)

In case PO~P5 showing ****. it means there is no data input


- 3) Press [NOΔ] / [NO∇] , when the PO----P5 selection.
- 4) Move the traverse stop position by [OPT5] / [OPT6] and then the will be traverse speed setting by [JOG SLOW]/[JOG FAST] .



5) After be decided stop position, press [SET] .


NOTE)

[PS] deter into the [PO] LCD indicators the message.



6) Set traverse speed by [INCR ▽] / [DECR ▲].
Press [INCR ▲]/[DECR ▽] the speed at the button of LCD change to 1. 2. 3. 4. 5.

7) Set the other speed in the same manner.



8) EXAMPLE P1 SETTING

- A) Press [MODE +] / [MODE -] to call the LCD message as shown below.

```
*TEACHING DATA*  
PART RELEASE  
P1=±***PS=±***  
SPEED=.....
```

- B) Press [OUT] to traverse out the robot to a part release position then the indication is shown as below.

```
*TEACHING DATA*  
PART RELEASE  
P1=±***PS=+1500  
SPEED=.....
```

- C) Press [SET] the set position is memorized.

Then the indication is as below.

```
*TEACHING DATA*  
PART RELEASE  
P1=+1500PS=+1500  
SPEED=.....
```

- D) Part releast position can be set by the above.

- 9) Set P1 P2 P3 P4 P5 The same operation.

STOP POSITIONS

P1 Part release stop position

```
*TEACHING DATA*  
PART RELEASE  
P1=±....PS=±....  
SPEED =..
```

P2 Sprue release stop position

```
*TEACHING DATA*  
SPRUE RELEASE  
P3=±....PS=±....  
SPEED =..
```

P3 Waiting nipper stop position

```
*TEACHING DATA*  
WAITING NIPPER  
P3=±....PS=±....  
SPEED =..
```

P4 Option 1 stop position

```
*TEACHING DATA*  
OP1 POSITION  
P4=±....PS=±....  
SPEED =..
```

P5 Option 2 stop position

```
*TEACHING DATA*  
OP1 POSITION  
P5=±....PS=±....  
SPEED =..
```

17. MULTI-ROW PLACING ON THE TRAVERSE BEAM

In case using conveyor or stocker, and required to place the parts in multiple rows, this function is utilized. The number of stops and pitch in between parts can be set.

SETTING

- 1) Turn the key switch to [PGM-MAN].
- 2) Press [MODE +]/[MODE -] to call the LCD message shown below.

```
*TEACHING DATA*  
MULTI ROW PLACE  
P=..... S=.....
```

- 3) Move cursor to which should be set by [ITEM ←]/[ITEM →] .

```
*TEACHING DATA*  
MULTI ROW PLACE  
P=... S=.....  
      □
```


CURSOR

P = PITCH

S = NUMBER OF MULTIPLE STOP.....MAX 20

Set proper value by [INCRΔ] / [DECR∇] .


- 1) Multi-row placing pitch setting
[INCRΔ] To increase value
[DECR∇] To decrease value



[UNIT 10] ...To increase/decrease value in 10 units

[UNIT 1] ...To increase/decrease value in 1 unit.

* [UNIT 10] / [UNIT 1] button should be pressed before [INCRΔ] / [DECR∇] button pressed.



18 . PROGRAM STORAGE

When set up the robot or operate robot by preset program, this function which has maximum 20 programs storage is very useful to save preparation time.

PROGRAM .SAVE

- 1) Turn the key switch to [PGM MAN].
- 2) Press [MODE +] / [MODE -] to call the LCD message as shown below.

```
*PROGRAM SET*
PRSNT No SET No
  = 01      = 01
SET THE PGM No
```

- 3) Press [INCR Δ]/[DECR ▽] and select the program number.

```
*PROGRAM SET*
PRSNT No SET No
  = 01      = 15
SET THE PGM NO
```

- 4) Press [PGM SAVE] then the indication is as below.

```
*PROGRAM SET*
PRSNT No SET No
  = 01 ==> = 15
SAVE BY [SET]KEY
```

- 5) Press [SET] and the message is shown on the LCD.

```
*PROGRAM SET*
PRSNT No SET No
  = 15 : = 15
SAVE FINISHED
```

- 6) The set program is memorized.

PROGRAM CALL

- 1) Turn the key switch to [PGM MAN].
- 2) Press [MODE +] / [MODE -] to call the LCD message as shown below.

```
*PROGRAM SET*
PRSNT No SET No
  = 01   = 01
SET THE PGM NO
```

- 3) Press [INCR] / [DECR] button and select the program number.

```
*PROGRAM SET*
PRSNT No SET No
  = 01   = 15
SET THE PGM NO
```

- 4) Press [PGM CALL] button.

```
*PROGRAM SET*
PRSNT No SET No
  = 01<== = 15
CALL PGM BY[SET]
```

5) Press [SET] to set the program number.


```
*PROGRAM SET*
PRSNT No SET No
  = 15      =15
CALL FINISHED
```

6) The program memorized in SET No.15 is called-up.

19. MECHANICAL MAIN/SUB STRIP STROKE ADJUSTMENT(OPTION) HE-ICC α TYPE.(standard) HIM TYPE(300.400 standard)

Adjustment of strip forward/backward position can be done on the HANDY console.

SETTING



- 1) Turn the key switch to [PGM·MAN].
- 2) Press [MODE+]/[MODE-] button to call the LCD message as shown below.

*AXIS ADJUSTMENT

MAIN [+ -]
SUB [+ -]

- 3) Press [STEP ADJ] button, then the following message is shown.

*AXIS ADJUSTMENT

STRIP STROKE
MAIN [+ -]
SUB [+ -]

4) MAIN/SUB strip stroke adjustment can be done by pressing [MAIN+ or -] / [SUB+ or -] button.

5) Press [STEP ADJ]. then the following message is shown

```
*AXIS ADJUSTMENT
STRIP BACK END
MAIN [+ -]
SUB  [+ -]
```


6) MAIN/SUB strip back end position can be adjusted by pressing [MAIN + or -] / [SUB + or -] button.

HIM TYPE (MOTORS)



1. Move E (Main arm fwd. end) by Motor A.
2. Move F (Main arm bwd. end) by Motor B.
3. Move G (Sub arm fwd. end) by Motor C.
4. Move H (Sub arm bwd. end) by Motor D.

HE-ICC α TYPE (MOTORS)



- A. Motor for adjustment of strip forward end position of MAIN ARM.
- B. Motor for adjustment of strip backward end position of MAIN ARM.
- C. Motor for adjustment of strip forward end position of SUB ARM.
- D. Motor for adjustment of strip backward end position of SUB ARM.

NOTE)

In case keep pushing [MAIN + , -] or [SUB + , -] button , alarm sounds when end limit switch of adjustment becomes on and adjustment motor can not be operated more then that point.

Get hand off from button to stop alarm.

Both auto operation and manual operation can be available even end limit switch of adjustment is on.

20. MECHANICAL MAIN/SUB VERTICAL STROKE ADJUSTMENTS. (HE-ICC α TYPE only)

Adjustment of MAIN/SUB arm vertical stroke can be done on the HANDY console.

SETTING

- 1) Turn the key switch to [PGM MAN].
- 2) Press [MODE +] or [MODE -] button to call the LCD message as shown below.

*AXIS ADJUSTMENT
MAIN [+ -]
SUB [+ -]

- 3) Press [ARM ADJ] button then the following message is shown .

*AXIS ADJUSTMENT
VERTICAL STROKE
MAIN [+ -]
SUB [+ -]

- 4) MAIN / SUB vertical stroke can be adjusted by pressing [MAIN + or -] / [SUB + or -] button.

NOTE)

In case keep pushing [MAIN + , -] or [SUB + , -] button , alarm sounds when end limit switch of adjustment becomes on and adjustment motor can not be operated more then that point.


Get hand off from button to stop alarm.

Both auto operation and manual operation can be available even end limit switch of adjustment is on.

HE-ICC_α TYPE (MOTORS)

A. Motor for adjustment of vertical stroke of MAIN ARM.


B. Motor for adjustment of vertical stroke of SUB ARM.



21. ERROR DISPLAY

Error message appears and alarm sounds also power goes off when miss operating or malfunction of INPUT/OUTPUT. Error number, error factor and countermeasure are shown on the LED.

Error display



- *1 Check the robot according to instruction on LCD.
- *2 Refer to attached "Designation of I/O " for checking the robot because ERROR/ALARM message does not cover all ERROR/ALARM cases.

- 1) Turn the key switch to [PGM·MAN] .
- 2) Press [CLR] button . alarm stops.
- 3) Press [POWER] switch then the ERROR/ALARM message disappears.

It is possible to re-display the error message that appeared directly before.

- 1) Turn the key switch to [PGM·MAN] then the indication is shown as below.

INITIALIZE
HOME RETRUN
UNDER MANUAL
MODE

- 2) Press [SET] button for about three seconds, then previous ERROR message appears.
- 3) Press [CLR] button. error message disappears.

ERROR !
E001
PRESS [POWER]

Unused

ERROR !
E002
PRESS
[ROBOT READY]

Unused

ERROR !
E003
PERFORM RETURN
TO HOME

Under the Auto operation, the condition of Home position is not enough.

Check that the following proximity switches and its wiring are not broken or loosed, and also these are set correctly.

Check point (when the arms are at the Home position)

- lot deccont safety (L-Y1):ON
- Main arm ascent end (L-Z1):ON
- Sub arm ascent end (L-H1):ON
- Main arm strip backward end (L-Y1):ON
- Sub arm strip backward end (L-W1):ON
- Wriot flip wotion end (L-E1):ON
- Part/Sprue etc. verification :OFF

After checking above points, return the Robot to Home position and press [AUTO START].

ERROR !
E004
SET KEY SWITCH
TO [AUTO]

Unused

ERROR !
E006
SET KEY SWITCH
[PGM.MAN] MODE

Before finished Initial setting,
the Key switch was set in RQRQT
OFF or AUTO position.
Set it PGM.MAN position.

ERROR !
E006
CHECK MOLD AREA
& PRESS [START]

Molded parts/Sprue were not
confirmed.
After checking the mold area,
press [START].

ERROR !
E007
CHECK EMERGENCY
STOP SWITCH

The Emergency switch is pressed.
Release the Emergency stop button.
(Unless it is released, you can not
clear the alarm.)

ERROR !
E008

unused

ERROR !
E009

Unused

ERROR !
E010

Unused

ERROR !
E011
CHECK MAIN ARM
ASC.END LS L-Z1

Main arm ascent end switch is abnormal.
Check that the Main arm ascent end switch and its wiring are not broken or loosed.

ERROR !
E012
CHECK MAIN ARM
ASC.SOL LS S-Z1

The solenoid valve for Main arm ascent is abnormal.
Check that the solenoid valve for Main arm ascent and its wiring are not broken or loosed.

ERROR !
E013
CHECK MAIN ARM
DESC.END LS L-Z2

Main arm descent end switch is abnormal.
Check that the Main arm descent end switch and its wiring are not broken or loosed.

ERROR !
E014
CHECK MAIN ARM
DESC.SOL LS S-Z2

The solenoid valve for Main arm descent is abnormal.
Check that the solenoid valve for Main arm descent and its wiring are not broken or loosed.

ERROR !
E015
CHECK MAIN STRIP
BWD.END LS L-Y1

main arm backward end switch is abnormal.
Check that the Main arm backward end switch and its wiring are not broken or loosed.

ERROR !
E016
CHECK MAIN STRIP
BWD.SOL S Y1

The solenoid valve for main arm backward is abnormal.
Check that the solenoid valve for Main arm backward and its wiring are not broken or loosed.

ERROR !
E017
CHECK MAIN STRIP
FWD.END LS L-Y2

Main arm forward end switch is abnormal.
Check that the Main arm forward end switch and its wiring are not broken or loosed.

ERROR !
E018
CHECK MAIN STRIP
FWD.EOL S Y2

The solenoid valve for Main arm forward is abnormal.
Check that the solenoid valve for Main arm forward end and its wiring are not broken or loosed.

ERROR !
E019
CHECK SUB ARM
ASC.FND I.S I.-H1

Sub arm ascent end switch is abnormal.
Check that the Sub arm ascent end switch and its wiring are not broken or loosed.

ERROR !
E020
CHECK SUB ARM
ASC.SOL I.S S-H1

The solenoid valve for Sub arm ascent is abnormal.
Check that the solenoid valve for Sub arm ascent and its wiring are not broken or loosed.

ERROR !
E021
CHECK SUB ARM
DESC.END LS L-H2

Sub arm descent end switch is abnormal.
Check that the Sub arm descent end switch and its wiring are not broken or loosed.

ERROR !
E022
CHECK SUB ARM
DESC.SOL I.S S-H2

The solenoid valve for Sub arm descent is abnormal.
Check that the solenoid valve for Sub arm descent and its wiring are not broken or loosed.

ERROR !
E023
CHECK SUB STRIP
BWD.END LS L-W1

Sub arm backward end switch is abnormal.
Check that the Sub arm backward end switch and its wiring are not broken or loosed.

ERROR !
E024
CHECK SUB STRIP
BWD.SOL S-W1

The solenoid valve for Sub arm backward is abnormal.
Check that the solenoid valve for Sub arm backward and its wiring are not broken or loosed.

ERROR !
E025
CHECK SUB STRIP
FWD.END LS L-W2

Sub arm forward end switch is abnormal.
Check that the Sub arm forward end switch and its wiring are not broken or loosed.

ERROR !
E026
CHECK SUB STRIP
FWD.SOL S-W2

The solenoid valve for Sub arm forward is abnormal.
Check that the solenoid valve for Sub arm forward and its wiring are not broken or loosed.

ERROR !
E027
CHECK WRIST VER
END LS L-R1

Wrist flip vertical end switch is abnormal.
Check that the Wrist flip vertical end switch and its wiring are not broken or loosed.

ERROR !
E028
CHECK WRIST VER
SOL S-R1

The solenoid valve for wrist flip vertical is abnormal.
Check that the solenoid valve for Wrist flip vertical and its wiring are not broken or loosed.

ERROR !
E029
CHECK WRIST HOR
END LS L-R2

Wrist flip horizontal end switch is abnormal.
Check that the Wrist flip horizontal end switch and its wiring are not broken or loosed.

ERROR !
E030
CHECK WRIST HOR
SOL S-R2

The solenoid valve for Wrist flip horizontal is abnormal.
Check that the solenoid valve for Wrist flip horizontal and its wiring are not broken or loosed.

ERROR !
E031
CHECK ROTATE
RET.END LS L-R3

Wrist rotate return end switch is abnormal.
Check that the Wrist rotate return end switch and its wiring are not broken or loosed.

ERROR !
E032
CHECK ROTATE
RET.SOL S-R3

The solenoid valve for Wrist rotate return is abnormal.
Check that the solenoid valve for Wrist rotate return and its wiring are not broken or loosed.

ERROR !
E033
CHECK ROTATE OUT
END LS L-R4

Wrist rotate out end switch is abnormal.
Check that the Wrist rotate out end switch and its wiring are not broken or loosed.

ERROR !
E034
CHECK ROTATE OUT
SOL S-R4

The solenoid valve for Wrist rotate out is abnormal.
Check that the solenoid valve for Wrist rotate out and its wiring are not broken or loosed.

ERROR !
E035
PART VERIFICATION
IS ON L.S-G1

Part verification is ON when the auto operation starts or finished one operating cycle. Check that the part verification switch is set at correct position and not broken, its wiring is not short circuit. The solenoid valve for part grip and its wiring should be also checked.

ERROR !
E036
PART VERIFICATION
IS OFF L.S-G1

Unused

ERROR !
E037
VACUUM VERIFICAT
IS ON L.S-G2

Vacuum verification is ON when the auto operation starts or finished one operating cycle. Check that the vacuum differential switch is not broken or its wiring is not short circuit. The solenoid valve for vacuum and its wiring should be also checked.

ERROR !
E038
VACUUM VERIFICAT
IS OFF L.S-G2

Unused

ERROR !
E039
M. SPRUE VERIFICA
IS ON L.S-G3

Main sprue grip verification is ON when the auto operation starts or finished one operating cycle. Check that the Main sprue grip verification switch is set at correct position and not broken, its wiring is not short circuit. The solenoid valve for main sprue grip and its wiring should be also checked.

ERROR !
E040
M. SPRUE VERIFICA
IS OFF L.S-G3

Unused

ERROR !
E041
SUB VERIFICATION
IS ON L.E C1

Sub grip verification is ON when the auto operation starts or finished one operating cycle.

Check that the sub grip verification switch is set at correct position and not broken, its wiring is not short circuit. The solenoid valve for sub grip and its wiring should be also checked.

ERROR !
E042
SUB VERIFICATION
IS OFF L.S-G4

Unused

ERROR !
E043
MAIN LOCK CYL
EXTENDED L.S-Z3

Unused

ERROR !
E044
SUB LOCK CYL
EXTENDED L.S-H3

Unused

ERROR !
E045
MAIN ASC/DESC LS
BOTH ON L-71.2

The main ascent and descent end signals are input simultaneously. Check that these switches are set at correct positions and not broken, these wirings are correct.

ERROR !
E046
SUB ASC/DESC LS
BOTH ON L-H1,2

The sub ascent end and descent end signals are input simultaneously. Check that these switches are set at correct positions and not broken, these wirings are correct.

ERROR !
E047
MAIN FWD/RWD LS
BOTH ON L-Y1,2

The Main forward end and backward end signals are input simultaneously. Check that these switches are set at correct positions and not broken, these wirings are correct.

ERROR !
E048
SUB FWD/BWD LS
BOTH ON L-Y1,2

The Sub forward end and backward end signals are input simultaneously. Check that these switches are set at correct positions and not broken, these wirings are correct.

ERROR !
E049
WRIST VER/HOR LS
BOTH ON L-R1,2

The Wrist vertical end and horizontal end signals are input simultaneously. Check that these switches are set at correct positions and not broken, these wirings are correct.

ERROR !
E050
ROTATE RET/OUT
BOTH ON L-R3,4

The Wrist rotation turn on and turn out end signals are input simultaneously. Check that these switches are set at correct positions and not broken, these wirings are correct.

ERROR !
E051
AIR PRESSURE
DOWN

Unused

ERROR !
E052
AIR PRESSURE
FAILURE

Unused

ERROR !
E053
ROBOT STANDARD
MOVEMENT ERROR

The following signals are not
input above the mold.

Signals

Main backward end or ascent end and
Wrist flip vertical end

Sub ascent end and Wrist flip
vertical end

Check that each switch and its wiring are not broken
or loosed.

ERROR !
E054
ROBOT OPTIONAL
MOVEMENT ERROR

Unused

ERROR !
E055

Unused

ERROR !
E056
TRAVERSE MIDWAY
ERROR

2nd descent safety off position data
does not accord with its data of
the last time.

Check that the 2nd descent safety
actuator is not moved.

If it has been moved, turn the breaker off after
indicating this error message and execute the initial
setting again. then also recheck the teaching data.

ERROR !
E057
CYCLE OVER ERROR

Under the Auto operation, the operating cycle from part verification to return to home position did not finish within 90 seconds.

ERROR !
E058

Unused

ERROR !
E059

Unused

ERROR !
E060

Unused

ERROR !
E061
1ST DESC. SAFETY
SIGNAL OFF L-X1

1st descent safety switch is OFF at the Home position. Check that the 1st descent safety actuator is set at the correct position. (Set it to actuate L-X1.)

ERROR !
E062
2ND DESC. SAFETY
SIGNAL OFF L-X2

2nd descent safety switch is OFF at the part/cprue release positions. Check that the 2nd descent safety actuator is set at the correct position. (Set it to actuate L-X2.)

ERROR !
E060
TRAVERSE OVERRUN
LS ON L-X3

The Robot overruns out.
Move the Robot toward the Home
position with the Manual operation
or the Teaching mode.

ERROR !
E064
TRAVERSE OVERRUN
LS ON L-X4

The Robot overruns out.
Move the robot toward the Home
position with the Manual operation
or the Teaching mode.

ERROR !
E065
NC NOT COMPLETE
ROM VERSION

The Robot did not stop within
the locational accuracy in spite of
10 tries positioning.
Check the backlash between traverse
motor gear and rack gear.

Turn slightly the level adjust (VR 1) on PCB M100
clockwise to stop within the locational accuracy under
the traverse motion.

ERROR !
E066
NC ACCURACY ERR
ROM VERSION

Unused

ERROR !
E067
ENCODER SIGNAL
ERROR ENCODER

This error is indicated under the
initial setting. (After finished
initial setting, the controller
indicates error No.70)
Check that the encoder and its cable
connector are not broken or loosed.

ERROR !
E068
INVERTER ERROR

Unused

ERROR !
E069
TRAVERSE MOTION
IMPOSSIBLE

The Robot can not traverse in spite of outputting the order of traverse motion.
Check that ascent and wrist flip vertical end switch is ON. If this error message is indicated at the ascent end position, check that the arms are not bounded.

ERROR !
E070
CHECK MOTOR
CIRCUIT

Traverse motor is abnormal.
Check following matters.

Inverter, motor, encoder and these wiring are not broken or loosed.

Backlash between motor and rack.

Motor brake is released.

Coupling of encoder is not loosed.

ERROR !
E071
CHECK EXTERNAL
DEVICE

Unused

ERROR !
E072
CHECK INTERFACE
WIRING W/I.M.M.

Unused

ERROR !
E073
INTERLOCK
NOT RELEASED

The key switch was turned to ROBOT OFF position under the Robot was not able to release interlock.
Move the Robot to Home position with manual operation and turn the key switch to ROBOT OFF position.

ERROR !
E074
MOLD OPEN END
SIGNAL OFF

Mold open end signal is OFF under
the mold safety interlock signal is
issued.
Check wirings for Main/Sub ascent end
signals and Mold open end signal.

ERROR !
E075
MOLD CLOSE END
SIGNAL OFF

Unused

ERROR !
E076
MOLD OPEN/CLOSE
SIGNAL BOTH ON

Mold open end signal and Mold close
end signal are input simultaneously.
Check wirings for mold open/close
end signals.

ERROR !
E077
SAFETY DOOR
CLOSE SIC. OFF

Safety door close signal is OFF
under the Auto operation.
Close Safety doors and check that
safety door close signal is input.

ERROR !
E078
INJECTION M/C
AUTO SIGNAL OFF

Check that injection molding machine
operates under AUTO/SEMI operation.

ERROR !
E079
EJECTOR FORWARD
END SIGNAL OFF

Unused

ERROR !
E080
INJECTION SIGNAL
OFF

Unused

ERROR !
E081
PART/RUNNER DROP
ON WAY OUT

Unused

ERROR !
E082
REMOVE THE WRIST
ROTATION UNIT

Unused

ERROR !
E091
BACK UP BATTERY
CHANGE BATTERY

Under-voltage of backup battery.
Replace the battery.
Unless it is replaced, programed
mold data is deleted. however
program of Rom chip is not deleted.

ERROR !
E096
OPTION 1 ERROR

Unused

ERROR !
E097
OPTION 2 ERROR

Unused

Conair has made the largest investment in customer support in the plastics industry. Our service experts are available to help with any problem you might have installing and operating your equipment. Your Conair sales representative also can help analyze the nature of your problem, assuring that it did not result from misapplication or improper use.

WE'RE HERE TO HELP

To contact Customer Service personnel, call:



HOW TO CONTACT CUSTOMER SERVICE

From outside the United States, call: 814-437-6861

You can commission Conair service personnel to provide on-site service by contacting the Customer Service Department. Standard rates include an on-site hourly rate, with a one-day minimum plus expenses.

If you do have a problem, please complete the following checklist before calling Conair:

- Make sure you have all model, serial and parts list numbers for your particular equipment. Service personnel will need this information to assist you.
- Make sure power is supplied to the equipment.
- Make sure that all connectors and wires within and between loading control and related components have been installed correctly.
- Check the troubleshooting guide of this manual for a solution.
- Thoroughly examine the instruction manual(s) for associated equipment, especially controls. Each manual may have its own troubleshooting guide to help you.
- Check that the equipment has been operated as described in this manual.
- Check accompanying schematic drawings for information on special considerations.

BEFORE YOU CALL ...

Additional manuals and prints for your Conair equipment may be ordered through the Customer Service or Parts Departments for a nominal fee.

EQUIPMENT GUARANTEE

Conair guarantees the machinery and equipment on this order, for a period as defined in the quotation from date of shipment, against defects in material and workmanship under the normal use and service for which it was recommended (except for parts that are typically replaced after normal usage, such as filters, liner plates, etc.). Conair's guarantee is limited to replacing, at our option, the part or parts determined by us to be defective after examination. The customer assumes the cost of transportation of the part or parts to and from the factory.

PERFORMANCE WARRANTY

Conair warrants that this equipment will perform at or above the ratings stated in specific quotations covering the equipment or as detailed in engineering specifications, provided the equipment is applied, installed, operated and maintained in the recommended manner as outlined in our quotation or specifications.

Should performance not meet warranted levels, Conair at its discretion will exercise one of the following options:


- Inspect the equipment and perform alterations or adjustments to satisfy performance claims. (Charges for such inspections and corrections will be waived unless failure to meet warranty is due to misapplication, improper installation, poor maintenance practices or improper operation.)
- Replace the original equipment with other Conair equipment that will meet original performance claims at no extra cost to the customer.
- Refund the invoiced cost to the customer. Credit is subject to prior notice by the customer at which time a Return Goods Authorization Number (RGA) will be issued by Conair's Service Department. Returned equipment must be well crated and in proper operating condition, including all parts. Returns must be prepaid.

Purchaser must notify Conair in writing of any claim and provide a customer receipt and other evidence that a claim is being made.

WARRANTY LIMITATIONS

Except for the Equipment Guarantee and Performance Warranty stated above, Conair disclaims all other warranties with respect to the equipment, express or implied, arising by operation of law, course of dealing, usage of trade or otherwise, including but not limited to the implied warranties of merchantability and fitness for a particular purpose.


INTERFACE BETWEEN THE ROBOT AND PRESS




名称	成形機 I/F 接続図 I
機種	KG
設計	作図 小平

株式会社 八一七


INTERFACE BETWEEN THE DUMMY PLUG AND PRESS




INTERFACE BETWEEN THE CONTROLLER AND PRESS



POWER SUPPLY DRAWING



KG-201 / 204 INVERTER DRAWING



取出機インバーター部

STF:SDと短絡で正転指令
 STR:SDと短絡で逆転指令
 SD:接点入力JEN端子


B,C:インバーターの保護回路が働いて異常となった時開放

2:周波数設定端子(減圧指令)
 5:周波数設定入力JEN端子

ピンNO	1	2	3	4	5	6
正転り	茶	黒	白	緑	青	レッド
逆転り	茶	白	黒	緑	青	レッド

PCB-E051

KG-203 INVERTER DRAWING



INPUT

NO.					
X 0		A	X41	RS	REJECTED PARTS
X 1		→ SHOULD BE OFF ←	X42	EJ	EJECTOR FWD. END
X 2		B X PULSE FOR HOME	X43	OP	PRESS O/P
X 3		Z	X44	EX	EXTERNAL DEVICE
X 4	L-RM5	MAIN DESC. +END (OP)	X45	ES	EMERGENCY STOP
X 5	L-RM6	MAIN DESC. -END (OP)	X46	L-X4	TRAVERSE OVERRUN -END
X 6	L-RM7	SUB DESC. +END (OP)	X47		KEY SWITCH 1
X 7	L-RM8	SUB DESC. -END (OP)	X50		KEY SWITCH 2
X10	L-Z1	MAIN ASC. END	X51		AUTO START SWITCH
X11	L-Z2	MAIN DESC. END	X52		AUTO STOP SWITCH
X12	L-Y1	MAIN STRIP BWD. END	X53		ROBOT READY SWITCH
X13	L-Y2	MAIN STRIP FWD. END	X54		POWER SWITCH
X14	L-X1	1ST DESC. SAFETY	X55	L-RM1	MAIN STRIP FWD. +END
X15	L-X2	2ND DESC. SAFETY	X56	L-RM2	MAIN STRIP BWD. -END
X16	L-X3	TRAVERSE OVERRUN +END	X57	L-RM3	SUB STRIP FWD. +END
X17	L-G1	PART VERIFICATION	X60	L-RM9	M. STRIP S/T END (OP)
X20	L-G2	VACUUM VERIFICATION	X61	L-RM10	M. STRIP S/T END (OP)
X21	L-G3	M. SPURE VERIFICATION	X62	L-RM11	S. STRIP S/T END (OP)
X22	L-G4	S. SPURE VERIFICATION	X63	L-RM12	S. STRIP S/T END (OP)
X23	L-R1	WRIST, VERTICAL END	X64		
X24	L-R2	WRIST HORIZONTAL END	X65		
X25	L-R3	ROTATE RETURN END (O/P)	X66		
X26	L-R4	ROTATE OUT END (O/P)	X67		
X27	L-H1	SUB ASC. END UC	X70		
X30	L-H2	SUB DESC. END	X71		
X31	L-W1	SUB STRIP BWD. END	X72		
X32	L-W2	SUB STRIP FWD. END	X73		
X33	L-P1	INPUT O/P 1	X74		
X34	L-P2	INPUT O/P 2	X75		
X35	MO	MOLD OPEN COMPLETE	X76		
X36	MC	MOLD CLOSE COMPLETE	X77		
X37	DR	SAFTY DOOR CLOSED			
X40	AT	PRESS IN AUTO			

*

*

OUTPUT


KG-201

NO.					
Y 0	CV	CONVEYOR	Y41		INVERTER DATA (D6)
Y 1	OP	OPTION	Y42		INVERTER DATA (D5)
Y 2	BZ	BUZZER	Y43		INVERTER DATA (D4)
Y 3	AT	ROBOT AUTO LED	Y44		INVERTER DATA (D3)
Y 4	RD	ROBOT READY LED	Y45		INVERTER DATA (D2)
Y 5	PW	POWER END	Y46		INVERTER ROTATION
Y 6		M1 ROTATION NOMAL			NORMAL/REVERSING
Y 7		M1 ROTATION REVERSE	Y47		INVERTER BREAK RELEASE
Y10	S-Z1	MAIN ASC. SOL	Y50		M2 ROTATION NOMAL
Y11	S-Z2	MAIN DESC. SOL	Y51		M2 ROTATION REVERSE
Y12	S-Y1	MAIN STRIP BWD. SOL	Y52		M3 ROTATION NOMAL
Y13	S-Y2	MAIN STRIP FWD. SOL	Y53		M3 ROTATION REVERSE
Y14	S-G1	GRIP SOL	Y54		M4 ROTATION NOMAL
Y15	S-G2	VACUUM SOL	Y55		M4 ROTATION REVERSE
Y16	S-G3	MAIN SPURE SOL	Y56	S-P3	OUTPUT OPTION 3
Y17	S-G4	SUB SPURE SOL	Y57		INVERTER MOTOR ON
Y20	S-R1	WRIST VERTICAL SOL	Y60		
Y21	S-R2	WRIST HORIZONTAL SOL	Y61		
Y22	S-R3	ROTATE RETURN SOL O/P	Y62		
Y23	S-R4	ROTATE OUT SOL O/P	Y63		
Y24	S-H1	SUB ASC. SOL	Y64		
Y25	S-H2	SUB DESC. SOL	Y65		
Y26	S-W1	SUB STRIP BWD. SOL	Y66		
Y27	S-W2	SUB STRIP FWD. SOL	Y67		
Y30	S-N1	NIPPER CUT SOL	Y70		
Y31	S-P1	CHUCK NIPPER SOL O/P	Y71		
Y32	S-P2	OPTION SOL	Y72		
Y33	MC	MOLD CLOSE SAFETY	Y73		
Y34	MO	MOLD OPEN SAFETY	Y74		
Y35	ST	MOLD CLOSING SAFETY	Y75		
Y36	EJ	EJECT TIMING CONTROL	Y76		
Y37	OP	PRESS OPTION	Y77		
Y40		INVERTER DATA (D7)			


OUTPUT

NO.					
Y 0	CV	CONVEYOR	Y41		INVERTER DATA (D6)
Y 1	OP	OPTION	Y42		INVERTER DATA (D5)
Y 2	BZ	BUZZER	Y43		INVERTER DATA (D4)
Y 3	AT	ROBOT AUTO LED	Y44		INVERTER DATA (D3)
Y 4	RD	ROBOT READY LED	Y45		INVERTER DATA (D2)
Y 5	PW	POWER END	Y46		INVERTER ROTATION
Y 6		M2 DRIVING MI(203)			NORMAL/REVERSING
Y 7		M1 DRIVING M2(203)	Y47		INVERTER BREAK RELEASE
Y10	S-Z1	MAIN ASC. SOL	Y50		M4 DRIVING M3(203)
Y11	S-Z2	MAIN DESC. SOL	Y51		M3 DRIVING M4(203)
Y12	S-Y1	MAIN STRIP BWD. SOL	Y52		M5 DRIVING M5(203)
Y13	S-Y2	MAIN STRIP FWD. SOL	Y53		M6 DRIVING M6(203)
Y14	S-G1	GRIP SOL	Y54		REMOCON MOTOR
Y15	S-G2	VACUUM SOL	Y55		REMOCON MOTOR REVERSE
Y16	S-G3	MAIN SPURE SOL	Y56	S-P3	OUTPUT OPTION
Y17	S-G4	SUB SPURE SOL	Y57		INVERTER MOTOR ON
Y20	S-R1	WRIST VERTICAL SOL	Y60		
Y21	S-R2	WRIST HORIZONTAL SOL	Y62		
Y22	S-R3	ROTATE RETURN SOL O/P	Y63		
Y23	S-R4	ROTATE OUT SOL O/P	Y64		
Y24	S-H1	SUB ASC. SOL	Y65		
Y25	S-H2	SUB DESC. SOL	Y66		
Y26	S-W1	SUB STRIP BWD. SOL	Y67		
Y27	S-W2	SUB STRIP FWD. SOL	Y70		
Y30	S-N1	NIPPER CUT SOL	Y71		
Y31	S-P1	CHUCK NIPPER SOL O/P	Y72		
Y32	S-P2	OPTION SOL	Y73		
Y33	MC	MOLD CLOSE SAFETY	Y74		
Y34	MO	MOLD OPEN SAFETY	Y75		
Y35	ST	MOLD CLOSING SAFETY	Y76		
Y36	EJ	EJECT TIMING CONTROL	Y77		
Y37	OP	PRESS OPTION			
Y40		INVERTER DATA (D7)			



INPUT A LED




INPUT B LED




INPUT E LED




OUTPUT F LED




OUTPUT B LED




OUTPUT D LED



I/F POWER SUPPLY



INPUT



I / F PCB-E100

FX-96BMT


- X 4 7 KEY SWITCH 1
- X 5 0 KEY SWITCH 2
- X 5 1 AUTO START S/W
- X 5 2 AUTO STOP S/W
- X 5 3 ROBOT READY S/W
- X 5 4 POWER S/W

- Y 0 3 ROBOT AUTO LED
- Y 0 4 ROBOT READY LED
- Y 0 5 POWER LED
- Y 0 2 BUZZER

- KEY SWITCH
- AUTO START SWITCH
- AUTO STOP SWITCH
- ROBOT READY SWITCH
- POWER SWITCH

- AUTO START
- ROBOT READY
- POWER
- EMERGENCY SWITCH
- BUZZER

INVERTER MOTOR




FX-96BMT


Y40	D7	2
Y41	D6	4
Y42	D5	6
Y43	D4	8
Y44	D3	10
Y45	D2	12

Y46	INVERTER ROTATION NORMAL/REVERSING	4
Y47	INVERTER BREAK RELEASE	16
Y57	INVERTER MOTOR ON	32
X00	A	2
X02	B	6
X03	Z	8


INPUT 1




INPUT 2




ROBOT INPUT DRAWING (option)




ROBOT INPUT DRAWING




KG-203 REMOCON




BOX




OUTPUT






OUTPUT (option)




OUTPUT



ALARM LIGHT PT - OP

I/P PCB - E100

OUTPUT (EXTERNAL DEVICE)



FX-96BMT

I/F PCB-E100

Y00 CONVEYOR

Y01 OP1

X44 EXTERNAL DEVICE

FKOUT1
CNO1
CON3

FKIN2
CNI2
CON2

P24

TBS2

CONVEYOR
CNV

EXTERNAL DEVICE START
EX ST


EXTERNAL OPTION 1
EX OP1

EXTERNAL OPTION
EX OP1
2ND. DESS. SAFETY
EX IL
COM

H24


INTERFACE BOARD

(PCB - E1001/F)




CR1-10, 19, 20: ATQ204 TQ2-24V
 CR11-18 : AGP2024 DSP2a-DC24V

- | | |
|-----------------------------|---------------------------------------|
| CR1 EMERGENCY STOP | CR12 MOLD OPEN SAFETY |
| CR2 MAIN ASCENT END | CR13 MOLD CLOSING SAFETY |
| CR3 1ST.DESCENT SAFETY | CR14 EJECT TIMING CONTROL |
| CR4 2ND.DESCENT SAFETY | CR15 PRESS OPTION |
| CR5 SUB ASCENT END | CR16 POWER LED. |
| CR6 MOLD OPEN COMPLETE | CR17 CONVEYOR |
| CR7 TRAVERSE RUN INTERLOCK | CR18 EXTERNAL OPTON 1 |
| CR8 MAIN/SUB DESCENT SAFETY | CR19 MOTOR ON |
| CR9 BUZZER | CR20 ROTATION NORMAL/REVERSING(motor) |
| CR10 ROBOT AUTO LED. | |
| CR11 MOLD CLOSES SAFETY | |




INPUT OUTPUT TERMINAL BOARD KG-201



PCB-E035

MADE IN JAPAN


INPUT OUTPUT TERMINAL BOARD KG-203



PCB-E043

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 pin No

INPUT OUTPUT TERMINAL BOARD KG-204



PCB-E052


pin No CNI ~ 28

KG - 201 REMOCON BOARD (E036)

M1 MAIN STRIP STROKE
 M2 MAIN STRIP END
 M3 SUB STRIP STROKE
 M4 SUB STRIP END


CR-1.3.5.7
 ROTATION NCVAL

CR-2.4.6.8
 ROTATION REVERS



M1 MAIN STRIP STROKE
M2 MAIN STRIP END
M3 SUB STRIP STROKE
M4 SUB STRIP END
M5 MAIN VERTICAL STROKE
M6 SUB VERTICAL STROKE

CR7 ROTATION NOMAL
CR8 ROTATION REVERSE
CR9 BRAKE RELEASE



E051B