

USERGUIDE

IMA-015-H2

10/94

# Feeder / Additive Metering Unit

## Models BF0 and BF6



### **WARNING - Reliance on this Manual Could Result in Severe Bodily Injury or Death!**

This manual is out-of-date and is provided only for its technical information, data and capacities. Portions of this manual detailing procedures or precautions in the operation, inspection, maintenance and repair of the product forming the subject matter of this manual may be inadequate, inaccurate, and/or incomplete and cannot be used, followed, or relied upon.

Contact Conair at [info@conairgroup.com](mailto:info@conairgroup.com) or 1-800-654-6661 for more current information, warnings, and materials about more recent product manuals containing warnings, information, precautions, and procedures that may be more adequate than those contained in this out-of-date manual.

## TABLE OF CONTENTS

---

<b>Safety Precautions</b> .....	3
<b>Specifications</b>	
Model BF0 Feeder .....	4
Model BF6 Feeder .....	5
<b>Installation</b> .....	6
<b>Control Overview</b>	
Injection Molding Controls .....	7
Extrusion Controls .....	7
Low Level Alarm (Optional) Sensor Adjustment .....	7
<b>Feeder Operation</b>	
Injection Molding Operation .....	9
Calibration .....	
Extrusion Operation .....	11
Calibration .....	
Useful Conversion Formulas .....	13
Motors (Model BF0 Only) .....	14
Approximate Feed Rates .....	14
Model BF0 .....	
Model BF6 .....	
Auger Removal (Model BF0 Only) .....	15
Emptying Supply Hopper .....	16
Accessories .....	17
<b>Appendix</b>	
Isolator Board Setup .....	19
Model BF0 Assembly .....	BF0
Model BF6 Assembly .....	BF6
Injection Molding Control Assembly .....	107-437
Injection Molding Schematic (115 VAC) .....	107-439-01
Injection Molding Schematic (230 VAC) .....	107-439-02
Extrusion Control Assembly .....	107-438
Extrusion Control Schematic (115 VAC) .....	107-440-01
Extrusion Control Schematic (230 VAC) .....	107-440-02
Low Level Alarm Assembly .....	107-451
Low Level Alarm Schematic (115/ 230 VAC) .....	107-452

## **SAFETY PRECAUTIONS**

---

### **SAFETY PRECAUTIONS:**

Although this product is designed with operator safety in mind, it is imperative that certain precautions be adhered to:


1. Keep fingers away from the auger! The auger is driven by a high torque gearmotor and is not easily stalled. Never place fingers or objects into the drainport (at the base of the hopper), the drive coupling area, or the throat adapter without first disconnecting the Feeder from the power source. Remove the auger for cleaning (see auger removal).
2. Disconnect all power when servicing control panel, including processing machine hookups.

Observing these two simple rules might prevent serious or fatal injury.



## **SPECIFICATIONS**

### **SPECIFICATIONS - MODEL BF6**



- Power Supply**      --5 AMPS at 115VAC - 1 Ph - 50/ 60 Hz  
                          --3 AMPS at 230VAC - 1 Ph - 50/ 60 Hz
- Motor**                --1/4 hp - 130 VDC PM Gearmotor - 62.5 RPM  
                          1/4 hp - 130 VDC PM Gearmotor - 42 RPM
- Auger**                --1" diameter (standard), 1/2", 3/4", 1-1/2" and 2" also available  
                          in both Pellet and Powder Clearances.
- Trigger Signal**     --(injection applications) External N.O. limit switch or an external  
                          115 VAC source. For other than 115 volt sources "PR" must be  
                          replaced with a relay of matching voltage.
- External Speed Control**     --(extrusion applications) 0 - 550 VDC

## **INSTALLATION**

---

### **INSTALLATION:**

1. The BF0 and BF6 Feeder throat adapters are factory drilled with a 5" sq. bolt pattern on top and bottom. The top plate is provided with (4) 3/8" - 16 UNC tapped holes to accommodate the Conair HandyHopper.

The bottom plate is provided with (4) clearance holes for 3/8" - 16 UNC bolt for mounting to machine. It may be necessary to fabricate an interface plate to fit between your machine and the feeder adapter.

2. The BF0 Feeder can mount to the adapter in two positions by reinstalling the three mounting bolts through the flanged portion of the auger casting.

The BF6 Feeder can mount in any of the four positions as follows:

1. Tilt Feeder canister mount slightly upward until front plate slides under holding bar. When canister mount is pushed to a horizontal position, it is then locked in place. Align hole in canister mount with hole in adapter housing by moving side to side as needed.
  2. Slide bushing toward base of auger housing and set canister in place. Hole in aluminum base must fit over pin in canister mount. Slide bushing into place and tighten thumb screw. Fasten clamps securing canister base.
3. Mount Conair HandyHopper or machine hopper on feeder adapter if included.
  4. Wire signal input(s) into the Feeder control (See "Control Functions and Hookups").
  5. Plug unit into a 115 VAC outlet and test operation.

For Injection Molding Models, test by setting the "Cycle Time" to a desired test interval, selecting a rate with the "Speed Adjust" pushbuttons, then moving the "Main Switch" to the CALIBRATE position and pressing the "Calibrate" pushbutton. Auger should turn freely and speed should adjust easily with "Speed Adjust" pushbuttons.

For Extruder Tracking Models, test by selecting a rate with the "Speed Adjust" pushbuttons and moving the "Main Switch" to the CALIBRATE position, then pressing and holding the "Calibrate" pushbutton. Auger should turn freely and speed should adjust easily with "Speed Adjust" pushbuttons while the "Calibrate" pushbutton is depressed.

## CONTROL OVERVIEW

### CONTROL FUNCTIONS AND SETUP

Two controls are offered: The injection molding and extruder tracking models, both shown on the following page. Their basic functions can be summarized as follows:

#### INJECTION MOLDING CONTROLS

These controls run intermittently based on a customer supplied start signal and timed interval, or customer supplied start and stop signals. Adjustments include timer and speed settings on the control front panel. Calibration can be accomplished through the on-board timer.

See appendix for wiring instructions contained in the following prints:

Control Assembly	107-437
Wiring Diagram (115 VAC)	107-439-01
Wiring Diagram (230 VAC)	107-439-02

#### EXTRUDER TRACKING CONTROLS

These controls run continuously and follow a customer supplied 0-550 V DC input signal from the extruder. Adjustments include the speed setting on control front panel and isolator board inside the control. **NOTE: See Appendix for Isolator Board Adjustment**

See appendix for wiring instructions contained in the following prints:

Control Assembly	107-438
Wiring Diagram (115 VAC)	107-440-01
Wiring Diagram (230 VAC)	107-440-02

#### LOW LEVEL ALARM OPTION


Available from factory or as a retrofit for 107-437 and 107-438 controls. Provides audio and visual alarms indicating material is low in Feeder Hopper.

Adjusting Sensor Sensitivity - Turn the trimpot clockwise until the LED energizes. Slowly turn the trimpot counter-clockwise until the LED de-energizes. Turn the trimpot an additional 1/2 turn counterclockwise. Check adjustment by holding your hand approximately 1/2" from the sensor tip and the LED should energize.


See appendix for wiring instructions contained in the following prints:

Alarm Assembly	107-451
Alarm wiring diagram	107-452

# CONTROL OVERVIEW



LAYOUT  
INJECTION  
CONTROL



LAYOUT  
EXTRUDER TRACKING  
CONTROL



## **FEEDER OPERATION**

### **INJECTION MOLDING OPERATION**

The Feeder starts and stops with a signal from the molding machine. This signal can either be a N.O. limit switch mounted on the machine, a set of relay contacts in the machine control, ("LS" on the wiring diagram) or a voltage signal from the injection machine control which is connected to relay coil "PR" in the feeder control.

After the Feeder control is wired to the desired mode of operation, set the Cycle Time pushbuttons on the control front panel to the desired time interval, then set the Speed Adjust pushbuttons to the desired rate setting (See Calibration below). Move the Main Toggle Switch to RUN mode and the Feeder operates automatically based on the molding machine input signal.

### **CALIBRATION**

Since different materials feed at different rates, it is necessary to calibrate the unit and make a small chart or graph for each material. This calibration should be set up in grams/ sec.

#### 1. Prepare to collect material samples:

Model BF0 - Remove the plexiglass cover plate from the adapter to provide access to the output of the auger using the attached scoop or small tray. NOTE: Larger material samples will require mounting Feeder on test stand or table top for access to adapter housing bottom outlet.

Model BF6 - Remove the Feeder from the adapter housing and place on a level test stand or table top. Material can be collected from the end of the auger as it's metered. NOTE: To access the Calibration Port, locate the sleeve on the auger housing, then loosen the thumbscrew and slide the sleeve back to expose the calibration port. This calibration port should only be used for verifying consistency of shot sizes during process, not for determining rates.

#### 2. Fill the Feeder hopper with material.


3. Flood the Feeder auger with material by running the Feeder until material starts to fall freely from the auger outlet. Run the Feeder as follows:

1. Set Speed Adjust to desired rate (ie: 500).
2. Set Cycle Time to desired interval (ie: 2-10 sec).
3. Move Main Switch to the CALIBRATE position.
4. Press the Calibrate pushbutton.

4. Retrieve the Feeder output for ten seconds at the desired rate (ie: Speed Adjust = 10, Cycle Time = 10 sec).

## FEEDER OPERATION

5. Weigh the material. This weight divided by ten (10) will provide the feed rate in grams per second at the given speed setting.
6. Collect and weigh material samples at various speed settings and prepare a chart or graph which might look like this:



Once a feed rate is established, simple mathematics will determine proper settings.

Example:

Injection time	-	5 sec.
Shot size	-	8 oz.
Let down	-	5 percent

$$\begin{array}{rcl}
 8 \text{ oz} \times 28.35 \text{ gms/oz} & = & 226.8 \text{ gms. (shot size in grams)} \\
 \times .05 & & (5\% \text{ let down}) \\
 \hline
 11.34 \text{ gms.} & & (\text{required to be spread over 5 sec.}) \\
 \div 5 \text{ sec.} & & (\text{injection time}) \\
 \hline
 2.27 \text{ gms/ sec.} & & 
 \end{array}$$

Looking on the chart, a feed rate of 2.25 gms/ sec is obtained at a speed setting of 60.

## **FEEDER OPERATION**

---

### **EXTRUSION OPERATION:**

In an extrusion setup, the auger runs continuously following a signal from the extruder (See Control Setup and Functions).

Once the extruder signal has been wired to the feeder and the isolator board adjusted, set the Speed Adjust pushbuttons to the desired rate setting (See Calibration below). Move the Main Toggle Switch to RUN mode and the Feeder operates automatically based on the extruder input signal.

### **CALIBRATION:**

Since different materials feed at different rates, it is necessary to calibrate the unit and make a small chart or graph for each material. This calibration should be set up in pounds/ hour.

#### **1. Prepare to collect material samples:**

**Model BF0** - Remove the plexiglass cover plate from the adapter to provide access to the output of the auger using the attached scoop or small tray. **NOTE:** Larger material samples will require mounting Feeder on test stand or table top for access to adapter housing bottom outlet.

**Model BF6** - Remove the Feeder from the adapter housing and place on a level test stand or table top. Material can be collected from the end of the auger as its metered. **NOTE:** To access the Calibration Port, locate the sleeve on the auger housing, then loosen the thumbscrew and slide the sleeve back to expose the calibration port. This calibration port should only be used for verifying consistency of shot sizes during process, not for determining rates.

#### **2. Fill the Feeder hopper with material.**


**3. Flood the Feeder auger with material by running the Feeder until material starts to fall freely from the auger outlet. Run the Feeder as follows:**

- 1. Set Speed Adjust to desired rate (ie: 500).**
- 2. Move Main Switch to the CALIBRATE position.**
- 3. Press and hold the Calibrate pushbutton. The Feeder auger will turn while the button is depressed - When material falls freely from the auger, release the Calibrate pushbutton.**

**4. Retrieve the Feeder output for ten seconds at the desired rate (ie: Speed Adjust = 10, hold Calibrate pushbutton for 10 sec). **NOTE:** In extrusion applications, longer calibration intervals will provide better accuracy when determining the Feeder rates for a given material.**

## FEEDER OPERATION

5. Weigh the material. For 10 sec samples, this weight multiplied by 360 will provide the feed rate in pounds/ hour at the given speed setting.
6. Collect and weigh material samples at various speed settings and prepare a chart or graph which might look like this:



Once a feed rate is established, simple mathematics will determine proper settings.

### Example:

Extruder throughput - 420 lbs/ hour

Let down - 5%

$$420 \times .05 = 21 \text{ lbs/ hour}$$

A setting of 70 will provide 21 lbs/ hr or 5% of the 420 lbs/ hr throughput. If a higher rate is needed than is shown on the chart, a larger auger should be used.

NOTE: It is not necessary to make graphs as shown above; charts similar to the following page will suffice.

## **FEEDER OPERATION**

---

<b>SPEED SETTING</b>	<b>RATE LBS/ HR</b>
20	6
40	12
60	18
80	24
100	30

In-between settings can be interpolated from this chart. Record and keep this information, so that a given material and auger combination need only be calibrated once.

**NOTE:** If more accurate, longer calibration tests are preferred, the Feeder Assembly can be unbolted and removed from the throat adapter for testing off the machine on a test stand or table top. With open access to the output of the auger, calibration tests of several minutes can be made and weighed.

### **USEFUL CONVERSION FORMULAS:**

#### **CONVERSION FORMULAS**

Oz x 28.35	= Grams
Grams x .035	= Oz
Grams x .0022	= Lbs
Lbs x 454	= Grams
Gms/ Min x .132	= Lbs/ Hr
Lbs/ Hr x 7.57	= Gms/ Min

## FEEDER OPERATION

### MOTORS : MODEL BF0

Three motors are available for the Conair Feeder: 8.7 RPM, 30 RPM, and 64 RPM. The speed control used with this system has a speed range of 50:1. This means that the standard 30 RPM motor will perform as low as .6 RPM. At slower settings the motor speed becomes erratic. The 8.7 RPM motor can be used for slower requirements. The 64 RPM motor can be used when the throughput requirements are greater than can be achieved with the 30 RPM motor - 1" auger combination.

### APPROXIMATE FEED RATES:

Use the following charts to determine approximate feed rates in grams/sec for injection applications or pounds/hr for extrusion.

NOTE: The rates shown in these charts are approximate and were determined utilizing free flowing, round pellets. Rates with other materials may vary. Test as described under "Calibration" to be sure.

**MODEL BF0 FEEDER**

<u>AUGER SELECTION</u>		<u>TYPICAL THROUGHPUT</u>	
Diam.	Pitch	Injection gms/ sec.	Extrusion lbs/ hr
3/8"	1/4"	.01 - .16	.08 - 1.4
3/8"	3/8"	.02 - .20	.10 - 1.7
1/2"	1/2"	.05 - .50	.20 - 4.0
3/4"	3/4"	.17 - 1.7	.70 - 14
1"	1"	.36 - 3.6	1.5 - 29

To determine approximate rates with optional drive motors, simply interpolate from the charts by dividing rates by 1/3 for the 8.7 RPM motor; or multiplying by 2 for the 64 RPM motor.

## **FEEDER OPERATION**

### **APPROXIMATE FEED RATES:**

#### **MODEL BF6 FEEDER**

<b>AUGER SELECTION</b>		<b>TYPICAL THROUGHPUT</b>	
Diam.	Pitch	Injection gms/ sec.	Extrusion lbs/ hr
1/2"	1/2"	.09 - .9	.4 - 7.0
3/4"	3/4"	.20 - 2.6	1 - 20
1"	1"	.60 - 6.0	3 - 50
1-1/2"	1-1/2"	1.0 - 19	7 - 150
2"	2"	2.0 - 40	15 - 300

### **AUGER REMOVAL: MODEL BF0**

NOTE: Augers are not interchangeable on the Model BF6 Feeder

1. Disconnect power to the control enclosure.
2. Loosen the two knobs that secure the motor/control assembly to the auger assembly. The motor can now be swung back out of the way.
3. Loosen and remove the two thumb screws that secure the retainer plate behind the auger drive coupling.
4. The auger (and housing if used) can now be pulled out of the cast aluminum feeder assembly.
5. To reinstall, reverse the above procedure.

## **FEEDER OPERATION**

---

### **EMPTYING SUPPLY HOPPER:**

#### **MODEL BF0**

The Feeder supply hopper can be removed for easy material changes and clean out.

Empty the supply hopper as follows:

1. Disconnect power. NOTE: The Feeder hopper with material slide gate is equipped with an electrical interlock to prevent the auger from turning when the hopper is removed. However, we recommend disconnecting power as an added precaution.
2. Turn off, or disconnect power to any hopper loading devices on the Feeder.
3. To remove supply hopper, first close material slidegate at base of hopper and lock in place with threaded fastener. Support supply hopper with hand and loosen clamp at base of hopper, then carefully lift hopper away from auger housing.
4. For full clean out, remove the auger as detailed above and clean out cast aluminum housing.

#### **MODEL BF6**

The Feeder hopper assembly and auger housing can be removed together for easy clean out and material changes. To remove, proceed as follows:

1. Disconnect power.
2. Turn off, or disconnect power to any hopper loading devices on the Feeder.
3. Loosen thumbscrew and slide bushing along auger housing away from throat adapter housing.
4. Unfasten clamps at canister base.
5. Move canister base forward far enough to separate motor drive pin from auger drive coupling.
6. Lift hopper assembly and auger housing away from canister mount.



## FEEDER OPERATION


### ACCESSORIES: (See following page for diagram)

1. For automatic filling of the Feeder hopper consult Conair for applicable vacuum loaders and loader/ lid adapters.
2. Spacers are available to raise the Feeder, or equipment mounted above it to provide clearance between the Feeder and associated equipment. The spacers can be used above or below the Feeder throat adapter.
3. Use of the Conair HandyHopper for base resin material supply is recommended. Capacity is 1-1/2 cu.ft. Conair manufactures a complete line of vacuum loaders to automatically fill supply hoppers. Consult your Conair Representative for the proper model for your application.
4. For quick clean out, Conair offers a spare Feeder hopper assembly with material slide gate and electrical interlock. (Model BF0 only - Not shown)
5. A material Low Level Alarm Kit is available for retrofit into the Feeder control with sensor for supply hopper.(Not shown - See "Control Operation")

<u>PART NUMBER</u>	<u>DESCRIPTION</u>
102-592-01	Spacer - drilled one end
102-592-02	Spacer - drilled both ends
140-032	HandyHopper
140-032-01	HandyHopper with magnet
611-084-F-006-09	Spare Feeder hopper with slide gate (Model BF0 only)
107-451-01	Low Level Alarm Kit (115 VAC)
107-451-02	Low Level Alarm Kit (230 VAC)

# FEEDER OPERATION

---



FEEDER ACCESSORIES

## APPENDIX

---

Feeder Board Calibration Procedure  
Model BFD Assembly  
Model BFD Assembly  
Injection Molding Control Assembly  
Injection Molding Schematic  
Injection Molding Schematic  
Extrusion Control Assembly  
Extrusion Control Schematic  
Extrusion Control Schematic  
Low Level Alarm Assembly  
Low Level Alarm Schematic

## APPENDIX

**Feeder Board Calibration Procedure** - This page contains the detailed steps on how to properly calibrate your feeder.

### PRE-SETUP

1. Disconnect all power to control box.
2. Follower drive board:
  - a. Move the *115-230 switch* to the 115 side.
  - b. Move the *90-180 switch* to the 90 side.
  - c. Turn the *accel trimmer pot* to the full counter-clockwise position.
  - d. Turn the *decel trimmer pot* to the full counter-clockwise position.
  - e. Turn the *max spd trimmer pot* to the midrange position.
  - f. Turn the *min spd trimmer pot* to the midrange position.
  - g. Set the *torque trimmer pot* as follows according to the horsepower of the motor.
    - 1/27 hp - set to the 9 O'Clock position
    - 1/8 hp - set to the 11 O'Clock position
    - 1/4 hp - set to the 12 O'Clock position
  - h. Set the *IR comp trimmer pot* as follows according to the horsepower of the motor.
    - 1/27 hp - set it to the 12 O'Clock position
    - 1/8 hp - set it to the 9 O'Clock position
    - 1/4 hp - set it to the 8 O'Clock position
3. Isolator Board (used on extruder tracking controls only):
  - a. Move the current/voltage switch to the voltage side.
  - b. Set the input trimmer pot to midrange.
  - c. Set the minimum output pot to midrange
  - d. Set the maximum output pot to midrange.

### CALIBRATION

1. Follower drive board.
  - a. Turn the power on.
  - b. Set the thumbwheel to "999".
  - c. Move the *run/cal switch* to the cal side.
  - d. Press and hold the cal button. The auger should turn.
  - e. Adjust the *max speed pot* until you read 90VDC on terminals 11 and 12.
  - f. Set the thumbwheel to "000".
  - g. Adjust the *min speed pot* until the motor just stops.
  - h. Set the thumbwheel to "999". Readjust the 90 VDC.
  - i. Set the thumbwheel to "000". Readjust the min speed pot.
  - j. Set the thumbwheel to "999". Check to see that the 90VDC is OK.
2. Isolator Board (used on extruder tracking controls only).
  - a. Turn the power on. Put control in "run".
  - b. Set the extruder to max. Set the thumbwheel to "999".
  - c. Adjust the *input trimmer pot* until the motor is getting 90VDC (terminals 11 and 12).
  - d. Set extruder to idle.
  - e. Adjust the *min output pot* carefully until the motor just stops turning.
  - f. Set extruder to max.
  - g. Adjust the *max output pot* until you read 90VDC on terminals 11 and 12
  - h. Set extruder to idle. Adjust the *min output pot* until the motor just stops
  - i. Set extruder to max. Adjust the *max output pot* until motor is getting 90VDC.
  - j. Set extruder to idle. Check to see that the motor stops.

---

Conair has made the largest investment in customer support in the plastics industry. Our service experts are available to help with any problem you might have installing and operating your equipment. Your Conair sales representative also can help analyze the nature of your problem, assuring that it did not result from misapplication or improper use.

## WE'RE HERE TO HELP

To contact Customer Service personnel, call:



## HOW TO CONTACT CUSTOMER SERVICE

**From outside the United States, call: 814-437-6861**

You can commission Conair service personnel to provide on-site service by contacting the Customer Service Department. Standard rates include an on-site hourly rate, with a one-day minimum plus expenses.

### **If you do have a problem, please complete the following checklist before calling Conair:**

- Make sure you have all model, serial and parts list numbers for your particular equipment. Service personnel will need this information to assist you.
- Make sure power is supplied to the equipment.
- Make sure that all connectors and wires within and between loading control and related components have been installed correctly.
- Check the troubleshooting guide of this manual for a solution.
- Thoroughly examine the instruction manual(s) for associated equipment, especially controls. Each manual may have its own troubleshooting guide to help you.
- Check that the equipment has been operated as described in this manual.
- Check accompanying schematic drawings for information on special considerations.

## BEFORE YOU CALL ...

*Additional manuals and prints for your Conair equipment may be ordered through the Customer Service or Parts Departments for a nominal fee.*

---

## EQUIPMENT GUARANTEE

Conair guarantees the machinery and equipment on this order, for a period as defined in the quotation from date of shipment, against defects in material and workmanship under the normal use and service for which it was recommended (except for parts that are typically replaced after normal usage, such as filters, liner plates, etc.). Conair's guarantee is limited to replacing, at our option, the part or parts determined by us to be defective after examination. The customer assumes the cost of transportation of the part or parts to and from the factory.

## PERFORMANCE WARRANTY

Conair warrants that this equipment will perform at or above the ratings stated in specific quotations covering the equipment or as detailed in engineering specifications, provided the equipment is applied, installed, operated and maintained in the recommended manner as outlined in our quotation or specifications.

Should performance not meet warranted levels, Conair at its discretion will exercise one of the following options:


- Inspect the equipment and perform alterations or adjustments to satisfy performance claims. (Charges for such inspections and corrections will be waived unless failure to meet warranty is due to misapplication, improper installation, poor maintenance practices or improper operation.)
- Replace the original equipment with other Conair equipment that will meet original performance claims at no extra cost to the customer.
- Refund the invoiced cost to the customer. Credit is subject to prior notice by the customer at which time a Return Goods Authorization Number (RGA) will be issued by Conair's Service Department. Returned equipment must be well crated and in proper operating condition, including all parts. Returns must be prepaid.

Purchaser must notify Conair in writing of any claim and provide a customer receipt and other evidence that a claim is being made.

## WARRANTY LIMITATIONS

**Except for the Equipment Guarantee and Performance Warranty stated above, Conair disclaims all other warranties with respect to the equipment, express or implied, arising by operation of law, course of dealing, usage of trade or otherwise, including but not limited to the implied warranties of merchantability and fitness for a particular purpose.**

QTY	REF ID	PART NUMBER	DESCRIPTION
1	1	191-358	ALUMIN HOUSING
1	2	109-055	NORMALLY CLOSED MOTOR MOTOR ASSEMBLY
1	3	102-433	
1	4	102-433	
1	5	102-433	
1	6	102-433	
1	7	102-433	
1	8	102-433	
1	9	102-433	
1	10	102-433	
1	11	102-433	
1	12	102-433	
1	13	102-433	
1	14	102-433	
1	15	102-433	
1	16	102-433	
1	17	102-433	
1	18	102-433	
1	19	102-433	
1	20	102-433	
1	21	102-433	
1	22	102-433	
1	23	102-433	
1	24	102-433	
1	25	102-433	
1	26	102-433	
1	27	102-433	
1	28	102-433	
1	29	102-433	
1	30	102-433	
1	31	102-433	
1	32	102-433	
1	33	102-433	
1	34	102-433	
1	35	102-433	
1	36	102-433	
1	37	102-433	
1	38	102-433	
1	39	102-433	
1	40	102-433	
1	41	102-433	
1	42	102-433	
1	43	102-433	
1	44	102-433	
1	45	102-433	
1	46	102-433	
1	47	102-433	
1	48	102-433	
1	49	102-433	
1	50	102-433	
1	51	102-433	
1	52	102-433	
1	53	102-433	
1	54	102-433	
1	55	102-433	
1	56	102-433	
1	57	102-433	
1	58	102-433	
1	59	102-433	
1	60	102-433	
1	61	102-433	
1	62	102-433	
1	63	102-433	
1	64	102-433	
1	65	102-433	
1	66	102-433	
1	67	102-433	
1	68	102-433	
1	69	102-433	
1	70	102-433	
1	71	102-433	
1	72	102-433	
1	73	102-433	
1	74	102-433	
1	75	102-433	
1	76	102-433	
1	77	102-433	
1	78	102-433	
1	79	102-433	
1	80	102-433	
1	81	102-433	
1	82	102-433	
1	83	102-433	
1	84	102-433	
1	85	102-433	
1	86	102-433	
1	87	102-433	
1	88	102-433	
1	89	102-433	
1	90	102-433	
1	91	102-433	
1	92	102-433	
1	93	102-433	
1	94	102-433	
1	95	102-433	
1	96	102-433	
1	97	102-433	
1	98	102-433	
1	99	102-433	
1	100	102-433	



CONAIR  
FRAMIN

BY FEELER ASSEMBLY

REVISIONS

NO.	DATE	DESCRIPTION
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		

REV. 2.0 2.0 2.0


DATE	BY	CHKD.	APP.





ITEM NO.	QUANTITY	PART NUMBER	DESCRIPTION
1	1	SEE CHART	ELECTRICAL PARTS
2	1	614-230-01	FEDER/AUGER PANEL COMMON PARTS
3	1	209-022-14	FUSE HOLDER
4	1	209-007-17	TERMINAL STRIP, 17 POINT LABEL
5	1	299-215-159-01	TERMINAL STRIP LABEL
6	1	SEE CHART	TERMINAL STRIP LABEL
7	1	SEE CHART	LINE CORD, #18-3 SJ.
8	30FT.	209-007-18	WIRE, #18 AWG-PVC
9	6	209-080-01	SOLDERLESS TERMINAL
10	3	209-080-02	SOLDERLESS TERMINAL
11	14	209-080-04	QUICK-DISCONNECT TERMINAL
12	7	209-080-05	QUICK-DISCONNECT TERMINAL
13	2	209-080-07	QUICK-DISCONNECT TERMINAL
14	2	209-080-48	QUICK-DISCONNECT TERMINAL
15	4	221-001-02	HEX NUT, #6-32

ITEM NO.	QUANTITY	PART NUMBER	DESCRIPTION
16	2	210-005-02	#6-32 X 3/8" U.S. S.S.
17	2	209-034-01	DECORATIVE NUT
18	1	SEE CHART	PLUG, 15AMP-240VAC
19	1	209-010-09	HOLE P-103
20	1	209-009-04	STRAIN RELIEF



**ORIGINAL**

CONAIR  
FRANKLIN  
LIMBO CYCLE FEEDER  
CONTROL BOX ASSEMBLY

FRANKLIN, VA.  
FRANKLIN, VA.  
18052


TOLERANCE UNLESS OTHERWISE SPECIFIED  
FRACTIONAL DECIMAL ANGLE

DATE: \_\_\_\_\_  
DRAWN BY: \_\_\_\_\_  
CHECKED BY: \_\_\_\_\_  
DATE: \_\_\_\_\_

NO.	DATE	REV.	BY	CHK.	DESCRIPTION
1		1			REVISED
2		2			REVISED
3		3			REVISED
4		4			REVISED
5		5			REVISED
6		6			REVISED
7		7			REVISED
8		8			REVISED
9		9			REVISED
10		10			REVISED
11		11			REVISED
12		12			REVISED
13		13			REVISED
14		14			REVISED
15		15			REVISED
16		16			REVISED
17		17			REVISED
18		18			REVISED
19		19			REVISED
20		20			REVISED

ITEM NUMBER	DESCRIPTION	PART NUMBER	DESCRIPTION
1	ELECTRICAL PARTS		
2	ELECTRICAL PARTS		
3	FUSE HOLDER		
4	TERMINAL STRIP, 16 POINT LABEL		
5	TERMINAL STRIP LABEL		
6	LINE COIL, #1R-3 SJ		
7	WIRE, #18 AWG-PVC		
8	SOLDERLESS TERMINAL		
9	SOLDERLESS TERMINAL		
10	QUICK-DISCONNECT TERMINAL		
11	QUICK-DISCONNECT TERMINAL		
12	QUICK-DISCONNECT TERMINAL		
13	QUICK-DISCONNECT TERMINAL		
14	48-32 X 1/2" LG. R.P.M.S.		

ITEM NUMBER	DESCRIPTION	PART NUMBER	DESCRIPTION
15	OC001A PVC NUT		
16	FLUG, 15AMP-24VAC		
17	FOLF. P. J6		
18	STRAIN RELIEF		
19	NE EN		



CONAIR  
FRANKLIN

FOR SALE IN  
CALIFORNIA  
10352

VOLTAGE FOLLOWING LABEL  
FACILITY IDENTIFY FOR ASSEMBLY

SOLDERLESS TERMINAL IDENTIFIED  
FRONT PANEL ORIGINAL

DATE: 10-1-68  
BY: [Signature]  
REV: 1

614-7774



DATE	BY	DESCRIPTION	REV
10-1-68	[Signature]	RELEASED	1
10-1-68	[Signature]	REVISED	2
10-1-68	[Signature]	REVISED	3
10-1-68	[Signature]	REVISED	4

DATE	BY	DESCRIPTION	REV
10-1-68	[Signature]	RELEASED	1
10-1-68	[Signature]	REVISED	2
10-1-68	[Signature]	REVISED	3
10-1-68	[Signature]	REVISED	4





SYMBOL	ITEM NO.	QUANTITY	PART NUMBER	DESCRIPTION
IFU	1	1	206-008-04	FUSE 5AMP
2FU	2	1	206-058-01	FUSE 1AMP
YS	3	1	203-001-21	SWITCH, 3 POSITION, 3PDT
IPB	4	1	203-001-07	PURKAITON, K.O.
IL	5	1	204-021-09	PILOT LIGHT, WHITE
IL	6	1	204-021-10	PILOT LIGHT, GREEN
SC	7	REF	208-514-05	SPEED CONTROL NO #KBC-2400
POT	18	REF	1205-132-C1	POT, 5K, 2W, DIGITAL, DOLBY B
1 ISDR	1	REF	1207-213-C1	ISOLATION BOARD NO PMS: -2403
MTR	10	REF	209-513-C2	MOTOR
ILS	11	REF	208-111-05	MAGNETIC SWITCH
ILS	12	REF	208-111-06	MAGNETIC SWITCH ACTUATOR



TERMINAL STRIP

NOTES:

- FOR BALANCE OF FEEDER, TURN 1E TO THE CALIBRATION POSITION AND PUSH IPB, HOLD 10E IN THE 2ND POSITION FOR THE TIME REQUIRED FOR CALIBRATION.
- IF A N.C. CONTACT ON THE EXTENDER IS USED TO START FEEDER, REMOVE WIRE JUMPER BETWEEN TERMINALS #4 AND #6, AND WIRE CONTACT TO TERMINALS #4 AND #6.
- TO OPERATE FEEDER IN CONJUNCTION WITH EXTENDER N.C. CONTACT AND WITH FEEDER NOT BEING SLAVED TO EXTENDER MOTOR, ADD JUMPER BETWEEN TERMINALS #9 AND #13 AND DISCONNECT WIRE FROM BOARD. THESE WIRE ARE TAKEN FROM 11E AND 13E ON 1 ISD BOARD. SPLICE TOGETHER AND INSULATE.
- ALL WIRING TO BE IN ACCORDANCE WITH ALL NAT OSHA AND LOCAL ELECTRICAL CODES AND PERFORMED BY A QUALIFIED ELECTRICIAN.



CCNAIR	FRANKLIN
FEEDER SCHEMATIC	120VAC
TOLERANCE UNLESS OTHERWISE SPECIFIED	AS SHOWN
DATE	014-229-02-01A



SEE ENG. 014-229-01 FOR ASSUR. V. 12/74

RELEASED	DATE
02-15-1975	014-229-02-01A

SYMBOL	ITEM NUMBER	QUANTITY	PART NUMBER	DESCRIPTION
1-2FU	1	2	206-066-03	FUSE 3AMP
3-4FU	2	2	206-066-01	FUSE 1AMP
15	3	1	203-001-22	SWITCH, 3 POSITION, 4PDT
14B	4	1	202-001-02	PURIFICATION, N.O.
11T	5	1	204-021-11	PILOT LIGHT, WHITE, 220VAC
2LT	6	1	204-021-12	PILOT LIGHT, GREEN, 220VAC
BC 7	REF		203-514-05	SPEED CONTROL KB #HEIC-2400
POY 8	REF		206-102-01	#DT, SK, 2W, DIGITAL, 60W/60V
1:5049	1		107-273-01	POSITION BOARD KB #KBSJ-2400
MTB 10	REF		209-513-02	MOTOR
1LS 11	REF		206-111-05	MAGNETIC SWITCH
1LS 12	REF		209-111-06	MAGNETIC SWITCH ACTUATOR





- NOTES:
- FOR CALIBRATION OF FEEDER, TURN IS TO THE CALIBRATE POSITION AND PUSH UP, HOLD 1PB IN THE CLOSED POSITION FOR THE TIME REQUIRED FOR CALIBRATION.
  - IF A N.O. CONTACT ON THE EXTENDER IS USED TO START FEEDER, REMOVE WIRE JUMPER BETWEEN TERMINALS #4 AND #6, AND WIRE CONTACT TO TERMINALS #4 AND #6.
  - TO OPERATE FEEDER IN CONNECTION WITH EXTENDER N.O. CONTACT AND WITH FEEDER NOT BEING SLAVED TO EXTENDER, NO OTHER JUMPER BETWEEN TERMINALS TO EXTENDER SHOULD BE USED. WIRE FROM BOARD #11 THESE ARE (3) #10 WIRES ON 1-150 BOARD SPLICE TOGETHER AND INSULATE.
  - ALL WIRING TO BE IN ACCORDANCE WITH ALL NATIONAL AND LOCAL ELECTRICAL CODES AND PERFORMED BY A QUALIFIED ELECTRICIAN.

CONAIR		FRANKLIN	FEEDER SCHEMATIC
TOLERANCE UNLESS OTHERWISE SPECIFIED		FRACTIONAL	DECIMAL
FRANKLIN		DATE	REV
10-14-66		DATE	REV
DR. J. J. L. 9-15, 614-239-02-02 A			

SEE FIG. 277, 283-03 FOR ASSEMBLY DRAWING REF. 107-440-82

DATE	10-10-66	RELEASED	BY	S.O.	APP.
85/151048					

ITEM NO.	NUMBER REQUIRED	PART NUMBER	DESCRIPTION
1	1	CHART	ELECTRICAL PARTS
2	1	102-877	PANEL MOUNTING LABEL
3	1	107-453-01	TERMINAL STRIP LABEL
4	1	107-453-02	TERMINAL STRIP LABEL
5	1	209-007-04	TERMINAL STRIP, 4 POS.
6	1	209-009-09	BUSHING
7	2	210-148-02	#4-40 X 1/4" LG. R.H.M.S.
8	2	210-003-02	#6-32 X 1/4" LG. R.H.M.S.
9	4	209-080-51	O.C. TERM., 90DEG., #18-22AWG
10	1	209-080-55	O.C. TERM., 90DEG., #18-22AWG
11	1	209-080-0E	O.D. TERM., #14-16AWG
12	1	209-080-52	O.D. TERM., 90DEG., #14-15AWG
13	1	105-195	SENSOR MOUNT SIGHT GLASS
14	1	208-008-07	CONNECTOR, TWIST LOCK, MALE
15	1	208-008-08	CONNECTOR, TWIST LOCK, FEMALE



CONAIR  
FRANKLIN  
FRANKLIN, PENNSYLVANIA  
16323

HOPPER LOW LEVEL  
ALARM PANEL ASSEMBLY

TOLERANCE UNLESS OTHERWISE SPECIFIED  
FRACTIONAL DECIMAL ANGULAR

DRW. MEANS	CHKD.	APP.
DATE 04-13-93	DATE	DATE
SHT. 1 OF 1 SHTS.		107-451 0


NO.	DATE	REVISIONS	BY	CHKD.	APP.	PART NO.	IT. #1 PART NO.	APPLICATION
D	09-06-93		PER EGN #93430	MEM		107-451-01	107-452-01	120VAC
C	08-03-93		PER EGN #93394	MEM		107-451-02	107-452-02	220VAC
B	06-11-93		PER EGN #93278	MEM				

REV.	DATE	DESCRIPTION
1	1-20-51	REVISED
2	2-10-51	REVISED
3	3-10-51	REVISED
4	4-10-51	REVISED
5	5-10-51	REVISED
6	6-10-51	REVISED
7	7-10-51	REVISED
8	8-10-51	REVISED
9	9-10-51	REVISED
10	10-10-51	REVISED
11	11-10-51	REVISED
12	12-10-51	REVISED
13	1-10-52	REVISED
14	2-10-52	REVISED
15	3-10-52	REVISED
16	4-10-52	REVISED
17	5-10-52	REVISED
18	6-10-52	REVISED
19	7-10-52	REVISED
20	8-10-52	REVISED
21	9-10-52	REVISED
22	10-10-52	REVISED
23	11-10-52	REVISED
24	12-10-52	REVISED
25	1-10-53	REVISED
26	2-10-53	REVISED
27	3-10-53	REVISED
28	4-10-53	REVISED
29	5-10-53	REVISED
30	6-10-53	REVISED
31	7-10-53	REVISED
32	8-10-53	REVISED
33	9-10-53	REVISED
34	10-10-53	REVISED
35	11-10-53	REVISED
36	12-10-53	REVISED
37	1-10-54	REVISED
38	2-10-54	REVISED
39	3-10-54	REVISED
40	4-10-54	REVISED
41	5-10-54	REVISED
42	6-10-54	REVISED
43	7-10-54	REVISED
44	8-10-54	REVISED
45	9-10-54	REVISED
46	10-10-54	REVISED
47	11-10-54	REVISED
48	12-10-54	REVISED
49	1-10-55	REVISED
50	2-10-55	REVISED
51	3-10-55	REVISED
52	4-10-55	REVISED
53	5-10-55	REVISED
54	6-10-55	REVISED
55	7-10-55	REVISED
56	8-10-55	REVISED
57	9-10-55	REVISED
58	10-10-55	REVISED
59	11-10-55	REVISED
60	12-10-55	REVISED
61	1-10-56	REVISED
62	2-10-56	REVISED
63	3-10-56	REVISED
64	4-10-56	REVISED
65	5-10-56	REVISED
66	6-10-56	REVISED
67	7-10-56	REVISED
68	8-10-56	REVISED
69	9-10-56	REVISED
70	10-10-56	REVISED
71	11-10-56	REVISED
72	12-10-56	REVISED
73	1-10-57	REVISED
74	2-10-57	REVISED
75	3-10-57	REVISED
76	4-10-57	REVISED
77	5-10-57	REVISED
78	6-10-57	REVISED
79	7-10-57	REVISED
80	8-10-57	REVISED
81	9-10-57	REVISED
82	10-10-57	REVISED
83	11-10-57	REVISED
84	12-10-57	REVISED
85	1-10-58	REVISED
86	2-10-58	REVISED
87	3-10-58	REVISED
88	4-10-58	REVISED
89	5-10-58	REVISED
90	6-10-58	REVISED
91	7-10-58	REVISED
92	8-10-58	REVISED
93	9-10-58	REVISED
94	10-10-58	REVISED
95	11-10-58	REVISED
96	12-10-58	REVISED
97	1-10-59	REVISED
98	2-10-59	REVISED
99	3-10-59	REVISED
100	4-10-59	REVISED
101	5-10-59	REVISED
102	6-10-59	REVISED
103	7-10-59	REVISED
104	8-10-59	REVISED
105	9-10-59	REVISED
106	10-10-59	REVISED
107	11-10-59	REVISED
108	12-10-59	REVISED
109	1-10-60	REVISED
110	2-10-60	REVISED
111	3-10-60	REVISED
112	4-10-60	REVISED
113	5-10-60	REVISED
114	6-10-60	REVISED
115	7-10-60	REVISED
116	8-10-60	REVISED
117	9-10-60	REVISED
118	10-10-60	REVISED
119	11-10-60	REVISED
120	12-10-60	REVISED
121	1-10-61	REVISED
122	2-10-61	REVISED
123	3-10-61	REVISED
124	4-10-61	REVISED
125	5-10-61	REVISED
126	6-10-61	REVISED
127	7-10-61	REVISED
128	8-10-61	REVISED
129	9-10-61	REVISED
130	10-10-61	REVISED
131	11-10-61	REVISED
132	12-10-61	REVISED
133	1-10-62	REVISED
134	2-10-62	REVISED
135	3-10-62	REVISED
136	4-10-62	REVISED
137	5-10-62	REVISED
138	6-10-62	REVISED
139	7-10-62	REVISED
140	8-10-62	REVISED
141	9-10-62	REVISED
142	10-10-62	REVISED
143	11-10-62	REVISED
144	12-10-62	REVISED
145	1-10-63	REVISED
146	2-10-63	REVISED
147	3-10-63	REVISED
148	4-10-63	REVISED
149	5-10-63	REVISED
150	6-10-63	REVISED
151	7-10-63	REVISED
152	8-10-63	REVISED
153	9-10-63	REVISED
154	10-10-63	REVISED
155	11-10-63	REVISED
156	12-10-63	REVISED
157	1-10-64	REVISED
158	2-10-64	REVISED
159	3-10-64	REVISED
160	4-10-64	REVISED
161	5-10-64	REVISED
162	6-10-64	REVISED
163	7-10-64	REVISED
164	8-10-64	REVISED
165	9-10-64	REVISED
166	10-10-64	REVISED
167	11-10-64	REVISED
168	12-10-64	REVISED
169	1-10-65	REVISED
170	2-10-65	REVISED
171	3-10-65	REVISED
172	4-10-65	REVISED
173	5-10-65	REVISED
174	6-10-65	REVISED
175	7-10-65	REVISED
176	8-10-65	REVISED
177	9-10-65	REVISED
178	10-10-65	REVISED
179	11-10-65	REVISED
180	12-10-65	REVISED
181	1-10-66	REVISED
182	2-10-66	REVISED
183	3-10-66	REVISED
184	4-10-66	REVISED
185	5-10-66	REVISED
186	6-10-66	REVISED
187	7-10-66	REVISED
188	8-10-66	REVISED
189	9-10-66	REVISED
190	10-10-66	REVISED
191	11-10-66	REVISED
192	12-10-66	REVISED
193	1-10-67	REVISED
194	2-10-67	REVISED
195	3-10-67	REVISED
196	4-10-67	REVISED
197	5-10-67	REVISED
198	6-10-67	REVISED
199	7-10-67	REVISED
200	8-10-67	REVISED
201	9-10-67	REVISED
202	10-10-67	REVISED
203	11-10-67	REVISED
204	12-10-67	REVISED
205	1-10-68	REVISED
206	2-10-68	REVISED
207	3-10-68	REVISED
208	4-10-68	REVISED
209	5-10-68	REVISED
210	6-10-68	REVISED
211	7-10-68	REVISED
212	8-10-68	REVISED
213	9-10-68	REVISED
214	10-10-68	REVISED
215	11-10-68	REVISED
216	12-10-68	REVISED
217	1-10-69	REVISED
218	2-10-69	REVISED
219	3-10-69	REVISED
220	4-10-69	REVISED
221	5-10-69	REVISED
222	6-10-69	REVISED
223	7-10-69	REVISED
224	8-10-69	REVISED
225	9-10-69	REVISED
226	10-10-69	REVISED
227	11-10-69	REVISED
228	12-10-69	REVISED
229	1-10-70	REVISED
230	2-10-70	REVISED
231	3-10-70	REVISED
232	4-10-70	REVISED
233	5-10-70	REVISED
234	6-10-70	REVISED
235	7-10-70	REVISED
236	8-10-70	REVISED
237	9-10-70	REVISED
238	10-10-70	REVISED
239	11-10-70	REVISED
240	12-10-70	REVISED
241	1-10-71	REVISED
242	2-10-71	REVISED
243	3-10-71	REVISED
244	4-10-71	REVISED
245	5-10-71	REVISED
246	6-10-71	REVISED
247	7-10-71	REVISED
248	8-10-71	REVISED
249	9-10-71	REVISED
250	10-10-71	REVISED
251	11-10-71	REVISED
252	12-10-71	REVISED
253	1-10-72	REVISED
254	2-10-72	REVISED
255	3-10-72	REVISED
256	4-10-72	REVISED
257	5-10-72	REVISED
258	6-10-72	REVISED
259	7-10-72	REVISED
260	8-10-72	REVISED
261	9-10-72	REVISED
262	10-10-72	REVISED
263	11-10-72	REVISED
264	12-10-72	REVISED
265	1-10-73	REVISED
266	2-10-73	REVISED
267	3-10-73	REVISED
268	4-10-73	REVISED
269	5-10-73	REVISED
270	6-10-73	REVISED
271	7-10-73	REVISED
272	8-10-73	REVISED
273	9-10-73	REVISED
274	10-10-73	REVISED
275	11-10-73	REVISED
276	12-10-73	REVISED
277	1-10-74	REVISED
278	2-10-74	REVISED
279	3-10-74	REVISED
280	4-10-74	REVISED
281	5-10-74	REVISED
282	6-10-74	REVISED
283	7-10-74	REVISED
284	8-10-74	REVISED
285	9-10-74	REVISED
286	10-10-74	REVISED
287	11-10-74	REVISED
288	12-10-74	REVISED
289	1-10-75	REVISED
290	2-10-75	REVISED
291	3-10-75	REVISED
292	4-10-75	REVISED
293	5-10-75	REVISED
294	6-10-75	REVISED
295	7-10-75	REVISED
296	8-10-75	REVISED
297	9-10-75	REVISED
298	10-10-75	REVISED
299	11-10-75	REVISED
300	12-10-75	REVISED
301	1-10-76	REVISED
302	2-10-76	REVISED
303	3-10-76	REVISED
304	4-10-76	REVISED
305	5-10-76	REVISED
306	6-10-76	REVISED
307	7-10-76	REVISED
308	8-10-76	REVISED
309	9-10-76	REVISED
310	10-10-76	REVISED
311	11-10-76	REVISED
312	12-10-76	REVISED
313	1-10-77	REVISED
314	2-10-77	REVISED
315	3-10-77	REVISED
316	4-10-77	REVISED
317	5-10-77	REVISED
318	6-10-77	REVISED
319	7-10-77	REVISED
320	8-10-77	REVISED
321	9-10-77	REVISED
322	10-10-77	REVISED
323	11-10-77	REVISED
324	12-10-77	REVISED
325	1-10-78	REVISED
326	2-10-78	REVISED
327	3-10-78	REVISED
328	4-10-78	REVISED
329	5-10-78	REVISED
330	6-10-78	REVISED
331	7-10-78	REVISED
332	8-10-78	REVISED
333	9-10-78	REVISED
334	10	



ITEM NO	NUMBER REQUIRED	PART NUMBER	DESCRIPTION
1	1	SEE CHART	AUD. ALARM HORN
2	1	209-309-01	SENSOR, N.C.
3	1	SEE CHART	RELAY, SPDT
4	1	SEE CHART	PILOTLIGHT, RED
5	1	205-003-01-06-37	RESISTOR, 2K, 10W
6	1	202-001-02	PUSHBUTTON, N.O., MOMENTARY

120 OR 220VAC-1PH-50/60HZ  
SEE CHART BELOW



FRANKLIN, PENNSYLVANIA 15323

**CONAIR**  
**FRANKLIN**

REMOTE ALARM PANEL  
HOPPER LOW LEVEL  
WIRING DIAGRAM

TOLERANCE UNLESS OTHERWISE SPECIFIED  
FRACTIONAL DECIMAL ANGULAR

DRW. MEANS Dwg. APP.  
DATE 11-22-93 DATE DATE

SHT. 1 OF 1 SITS. 107-452 A

DESCRIPTION	PART NO.	IT.#1 PART NO.	IT.#3 PART NO.	IT.#4 PART NO.
120VAC	107-452-01	209-089-03	200-032-36	204-021-01
220VAC	107-452-02	209-089-34	200-032-09	204-021-03

NO DATE

RELEASED BY: KEN

REVISIONS BY: CAD. APP.