


Parts Identification Guide
PIP003/0306

Strand Pelletizers



300 Series







**Strand Pelletizers
300 Series**

- 1. Disconnect Handle
- 2. Start Button
- 3. Start Button (Air Blower)
- 4. Stop Button
- 5. Stop Button (Air Blower)
- 6. Potentiometer (Rotor)
- 7. Potentiometer (Feedroll)
- 8. Disconnect
- 9. Transformer
- 10. Drive, Motor
- 11. Breaker (4)
- 12. Relay



Strand Pelletizers 300 Series

- 12. Safety Switch
- 13. Motor
- 14. Adjustable Base
- 15. Gear Box
- 16. Air Cylinder
- 17. LFR Bearing
- 18. LFR Drive Belt
- 19. LFR Drive Pulley
- 20. Rotor Drive Belts
- 21. Rotor Drive Pulley
- 22. UFR Bearing



Strand Pelletizers 300 Series

- 23. Push / Pull Valve
- 24. Air / Filter Regulator
- 25. Rotor
- 26. Upper Feedroll