



Parts Identification Guide
PIC018/0305

CAML Loader





CAML Loader

1. Filter
2. Clamps
3. Sensor
4. Control
5. Filter Regulator
6. Compressed Air Filter
7. Sight Tube
8. Mounting Base
9. "MTD" Material Transfer Device
10. O-ring Coupling
11. Solenoid Valve