



Parts Identification Guide
PIE010/0405


PC Series Belt Puller





PC Puller

- | | |
|--------------------|-------------------------|
| 1. Transformer | 10. % Readout |
| 2. Overloads | 11. Start Button |
| 3. Disconnect | 12. Local / Remote |
| 4. Circuit Breaker | 13. Open / Close Switch |
| 5. Control Drive | 14. Stop |
| 6. Relay | 15. E-Stop |
| 7. Pressure Gauges | 16. Jog / Run Switch |
| 8. Regulators | 17. Potentiometer |
| 9. Feet per Minute | 18. Digital Readout |



PC Puller

- 19. Motor
- 20. Link Kit
- 21. 50-3 Chain