





Parts Identification Guide
PIC013/0205


Positive Displacement Pump 10, 15, 25 HP





**Positive Displacement Pump
10, 15, 25 Hp**

- 1. Belt Guard
- 3. Motor
- 4. Muffler
- 6. Sheave / Driven Bushing
- 7. V Belt
- 9. Vacuum Pump
- 10. Sheave / Drive Bushing



Positive Displacement Pump

10, 15, 25 Hp

- 1. Belt Guard
- 2. Filter Assembly
- 3. Motor
- 5. Relief Valve
- 8. Vacuum Gauge
- 9. Vacuum Pump