

# SmartServices® NEW FEATURES

We're always improving and adding features to SmartServices. If there's an improvement or feature you'd like to see on the Dashboard, please let us know by emailing [info@conairgroup.com](mailto:info@conairgroup.com).



## NOW INTRODUCING: SILO LEVEL MONITORING AND ALERTS!



Conair SmartServices can now display your silo level, and alert you to low level conditions before you run low on resin. SmartServices connected to your central conveying control (FLX-128 Plus, and SmartFLX) can now visually show you the silo level from your SmartBob level monitor in each silo.

You determine what KPI (Key Performance Indicators) you want to display at a glance on the dashboard, and you can immediately see (or be alerted to) silo level conditions.

### Visually see data for:

- Percentage full
- Actual weight
- Actual volume\*
- Silo weight capacity
- Silo volume capacity\*
- Resin name\*
- Level alarm settings\*

\*Note: Some KPI data not available for FLX-128 Plus control.



### How It Works:

- The SmartBob is already constantly reporting data to your central conveying control.
- The FLX-128 Plus, or SmartFLX are connected to your SmartServices dashboard.
- The dashboard visually displays this data, allowing you to choose which KPI to see at-a-glance.
- The dashboard allows you to set alarm levels, with notifications delivered to the appropriate personnel.
- Set the alert to notify procurement when it's time to order new resin. The alert can notify you of silo name, current levels, and resin name.